



EN ENGLISH



AX22

2-Door Expander

* Voir conditions de garantie à vie limitée. / Refer to Limited Lifetime Warranty.



Range: Online Access Control

INSTALLATION MANUAL

AX22

2-Door Expander

**Thank you for buying our products and for
the confidence you placed in CDVI.**

TABLE OF CONTENTS

1] PRODUCT PRESENTATION.	3
2] NOTES AND RECOMMENDATIONS.	4
FCC & IC Compliance	4
UL Compliance.	4
UL 294 Compliance Notice	4
Free Technical Support	4
Recommended Wiring.	5
Specifications	5
3] PACKAGE CONTENTS.	7
Content of the 2-Door Expander	7
Location and Mounting	8
4] MOUNTING INSTRUCTIONS	9
Installing the Tamper Switches	9
Installing the box lock	10
Fixing the Box to its Location	11
Installing the 2-Door Expander PC board	12
5] WIRING DIAGRAM	13
Connecting the Box Tamper Switches	13
Connecting Readers and Keypads	14
Connecting Inputs	15
Door - Locking Devices.	18
Power Connections.	20
LED Indicators.	23
Connecting Expander Modules to the Controller.	24
6] WARRANTY - TERMS & CONDITIONS	25

AX22

2-Door Expander

1] PRODUCT PRESENTATION

Up to four AX22 door expanders increase the AC22 main controller's capacity to 10 doors. Locate the AX22 anywhere on the 1220m (4000ft) 4 conductor RS485 communication bus. Effortless auto-detect technology identifies the AX22 on the communication bus. A pre-assembled universal power supply is included with every AX22 making this unit an industry leader in efficiency and simplicity.

- **Control 2 doors / 2 readers**
- **Auto-detect technology**
- **1220m (4000ft) 4 conductor RS-485 expansion bus (No jumpers or DIP switches)**
- **Field-selectable lock outputs:**
2 Form C relays (Dry Contact) 5A @ 250Vac, 7A @ 125Vac, 7A @ 30Vdc
- **Wiegand & ABA Track II magnetic stripe compatible**
- **10 Inputs (20 using zone doubling technology)**
- **Comprehensive LED status indicators**



AX22

2-Door Expander

2] NOTES AND RECOMMENDATIONS

FCC & IC Compliance

This device complies with Part 15 of the FCC rules Class A. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received including interference that may cause undesired operation. This class A digital apparatus meets all requirements of the Canadian Interference Causing Equipment Regulations. The ATRIUM AX22 2-Door Expander is also compliant with EN55022:1998, amendment 1:1995, Class A.

UL Compliance

To comply with UL listings, the following requirements must be met:

- Use of UL listed readers (Wiegand: 26-bit, 30-bit and 40-bit; mag stripe: up to 32 digits)
- Use of a UL recognized tamper switch on every housing cabinet for the AX22 2-Door Expander
- Use only UL listed cables
- Use only UL listed adaptors

Note: All circuits are power limited.

UL 294 Compliance Notice

- Use only UL 294 listed power supply
- Connect CDVI LED status indicator, part number 7020-0001-0000, to the DC Input gray terminals of the AX22.

Note: Backup battery provides operation of up to 12 hours but has been tested for 4 hours per Section 33 of UL 294, fifth edition.



The system's location and wiring methods shall be in accordance with the National Electrical Code, ANSI/NFPA 70.

Free Technical Support

For technical support in Canada or the U.S., call 1-866-610-0102, Monday to Friday from 8:00 a.m. to 8:00 p.m. EST. For technical support on the International, please see the last page of this document or visit our website: www.cdvigroup.com.

AX22

2-Door Expander

Recommended Wiring

Equipment	Wire Type	Size	Maximum Length
Card reader and Wiegand keypad	4 to 8 conductors, stranded, shielded (foil), drain conductor. For example: Alpha 5196, 5198, 5386, 5388, Belden 9553	22AWG (0.64mm) to 18AWG (1.02mm)	150m (500ft.)
Zone input	2 conductors, copper 22AWG (0.64mm)	22AWG (0.64mm)	600m (2000ft.)
Door strike	2 conductors, solid copper 18AWG (1.02mm)	18AWG (1.02mm)	150m (500ft.)
Power Supply	3 conductors, solid copper 18AWG (1.02mm)	14AWG (1.63mm)*	8m (25ft.)
RS485 bus, Star or Daisy Chain (no BIAS/EOL required)	CAT 5/5e or 4 pairs	24AWG (0.51mm)	1220m (4000ft.)
	4 conductors, copper	26AWG (0.40mm) to 18AWG (1.02 mm)	

* The Minimum Size Equipment Conductors for the AC mains required are 14 AWG if made of Copper or 12 AWG if made of Aluminium or Copper-Clad Aluminium. Do not use any switch-controlled outlets to power the system.

Specifications

System Resources	
Operating Temperature	-20°C to +70°C (-4°F to +158°F)
Humidity	0% to 85% (non condensing)
System Autonomy	Full Distributed Architecture (100% Off-line Operation)
Firmware	Online Upgradeable
PCB Dimensions	19.9cm (7.83") x 12.38 cm (4.875")
Cabinet Dimensions	29 cm (11.4") high, 28 cm (11") wide, 8 cm (3.15") deep

Inputs	
Readers	2 x Wiegand Readers with Multiple Protocol Support (Wiegand 26-bit, 30-bit & 44-bit), Magnetic Stripe ABA Track 2
Keypads	2 x Wiegand Keypad with Multiple Protocol Support (Wiegand 8-bit & 26-bit)
Multi-Purpose Inputs	10 zone inputs (up to 20 using ZONE DOUBLER) with optional individual WIRE CUT & WIRE SHORT supervision.
Box Tamper	Normally Closed (N.C.) contact

AX22

2-Door Expander

Communication

LOCAL BUS	RS485 @ 57600Baud supporting star and/or daisy chain topologies up to 4000ft (1220 meters)
-----------	--

Power Supply

AC Power	120-240Vac, 200VA
Frequency	50Hz/60Hz
Output	24Vdc, 3.5A
AC Terminal Fuse	250Vac, 2.5 A, Time Lag, Slow Blow, Operating Temperature: -55oC to +125oC
Power Loss Indicator	Yes (DC IN)



Do Not Connect to a Receptacle Controlled by a Switch.

On-Board Protection (All fuseless, auto-resume)

VLK	12Vdc @ 750mA
AUX	12Vdc @ 1A
Battery	Against reversal, short, current limited/monitored

Power output specifications

Battery Backup

Battery Capacity	12Vdc 7Ah rechargeable acid/lead or gel cell backup battery (UL/ULC: YUASA #NP7-12 recommended, Europe: CDVI B7AH recommended). Ensure proper polarity.
Charging Current	250mA (default), 320mA, 500mA, or 1A. Refer to the ATRIUM user interface instruction manual for more information on how to modify the battery charging current.
Low Battery @	11.8Vdc
Low Battery Restore @	12.2Vdc
Low Battery Cut-Off @	10.5Vdc

Power Outputs (+12Vdc)

Lock Output 1	Maximum Current 750mA
Lock Output 2	
Reader 1	Maximum Current 1000mA
Reader 2	
Zone Inputs	
LOCAL BUS	

Outputs

LK1 and LK2	Form C Relay, 5A @ 250Vac, 7A @ 125Vac, 7A @ 30Vdc
-------------	--

AX22

2-Door Expander








3] PACKAGE CONTENTS

This chapter details how to install and setup the ATRIUM 2-Door Expander.






Content of the 2-Door Expander

The 2-Door Expander contains:

- One 2-Door Expander module in its cabinet with connection diagram label
- AC power cord
- Metal Box kit:

							
	Wall Switch and a white wire (115mm) with a log at each end	Bolts and Nuts	Wall Switch Spacer	Door Switch and 2 white wire (350mm) with a log at one end	Door Switch Support	Metal box screw	Metal box lock and key
Metal Box Kit	1	2 each	1	1	1	4	1

If any item is missing, please notify your distributor immediately.

					
	Pair of Wire, Red and black, for backup battery (400mm)	1K Resistor	2.2K Resistor	Diode 1N4007 for the door strikes or locks	Fastener (PCB Holder)
Installation Kit	1 pair	20	10	2	5

AX22

2-Door Expander

Location and Mounting

The cabinet is designed to be installed indoors, in a safe and secure location. Suggested locations include electrical rooms, communication equipment rooms, closets or in the ceiling. To save time, wiring and facilitate testing, install the cabinets at an equal distance between its controlled doors. Normal temperature and humidity levels should be maintained.

Cabinet Dimensions:

40 cm (15.8") high, 32 cm (12.6") wide, 9 cm (3.54") deep

The Cabinet Can Accommodate:

One 12Vdc @ 4.5AH or 7AH, gel cell type batteries and wiring connections (15cm (6") high, 6cm (2.5") wide, 9 cm (3.54") deep)

Battery Model	Voltage	Capacity	Length	Width	Height
YUASA #NP7-12	12 Volt	7 Ah	151mm (5.94")	65mm (2.56")	97.5mm (3.84")
YUASA #NP4-12	12 Volt	4.5 Ah	90mm(3.54")	70mm (2.76")	106mm (4.17")

Multiple Conduit Knock-outs:

Two 19.05mm (0.75") on each side and one 12.7mm (0.5") on top

Minimum Clearance For Cabinet:

25cm (10") clear space around all sides

38cm (15") clear space in front of cabinet

Minimum Clearance From Electrical Interference:

2.4m (8ft.) from high voltage equipment or wiring and from electrical equipment likely to generate interference

1.2m (4ft.) from telephone equipment or lines and 8m (25ft.) from transmitting equipment



The system's location and wiring methods shall be in accordance with the National Electrical Code, ANSI/NFPA 70.

AX22

2-Door Expander

4] MOUNTING INSTRUCTIONS

The box needs to be prepared before fixing it to its location.

Installing the Tamper Switches

Installing tamper switches allows the 2-Door Expander to detect when the cabinet door is opened and/or when the cabinet is removed from the wall. If needed install the tamper switch(es) as follow.

1. Install the wall switch plastic spacer on the back at bottom left side of the box as show in the following picture.

Before



After



2. Install the wall tamper switch using the supplied bolts and nuts as shown in the following picture.
3. Install the door tamper switch by aligning the switch holes to the pre-installed plastic bracket pins. Press firmly to secure the tamper switch in position.




AX22 2-Door Expander

Installing the box lock


Installing the box lock allows to secure the box from non authorized access. If needed install the box lock as shown in the following picture (inside view of the door).

1. Remove the box door knock-out.
2. Insert the lock in the hole.
3. Slide the "U" metal part into the lock groove as shown in the following picture to secure the lock in place.



Alternatively or complementary to the box lock, the box may be secured by fixing the cover to its base using screws. However this should be done only once the installation of the full 2-Door Expander system is completed.

1. Use the 4 screws supplied to secure the box cover to its base as shown in the following picture.




AX22 2-Door Expander

Fixing the Box to its Location

Install the box to its location using 4 screws (not supplied) as shown in the following picture.



If the wall tamper switch is used, make sure that the tamper switch arm moves freely and is completely pushed in when the enclosure is installed on the wall.





AX22

2-Door Expander

Installing the 2-Door Expander PC board

Install the 5 fasteners (PCB holder) supplied respectively to the box holes identified in red in the following picture.




AX22**2-Door Expander**

5] WIRING DIAGRAM

Connecting the Box Tamper Switches

Connecting the tamper switches allows the 2-Door Expander to detect when the cabinet door is opened and/or when the cabinet is removed from the wall. To install the tamper switches, see "Installing the Tamper Switches". To use both switches:

1. Connect one end of the supplied wire, the one with a log at each end, to the door tamper switch terminal and the other end to the wall tamper switch terminal.
2. Connect the other terminal of the door tamper switch to the "TMP" terminals using the supplied wire.
3. Connect the other terminal of the wall tamper switch to the "GND" terminals using the supplied wire.



To use only one switch:

1. Connect one terminal of the tamper switch to the "TMP" terminals using the supplied wire.
2. Connect the other terminal of the same tamper switch to the "GND" terminals using the supplied wire.



If you do not use the tamper switch, connect a wire between the "TMP" and "GND" terminals.


AX22

2-Door Expander

Connecting Readers and Keypads

The 2-Door Expander allows automatic format detection and decoding of the connected reader/keypad. When installing a keypad with a Wiegand output, the keypad's "D0" and "D1" wires should be connected to the same terminals as the reader (the reader output must be open collector). Depending on the required application more than one keypad and/or reader can be connected to the same terminals.

Most readers and keypads have built-in buzzers and LEDs. These should be connected to module's programmable outputs (B1, G1, R1 for READER 1 and B2, G2, R2 for READER 2). These are open collector outputs capable of sinking 100mA. Please note that the B, G and R outputs are programmed for a 7-wire reader by default. Typically, a blue/red/green indicator on the reader will inform the card user that access has been granted (changes from blue to green), access has been denied (changes from blue to flashing red), door is locked (from blue to brief red) or door is unlocked by a schedule (changes from blue to brief green). Typically, the reader buzzer or an external sounding device will inform the card user that the door has been left open after a valid access or the door has been forced open. The functions of all these outputs are programmable through the ATRIUM software. The ATRIUM system is configured for the SOLAR, STAR and NANO models of readers by default (Standby blue).



See "Recommended Wiring" chapter for more information on wiring type, size, and maximum length. Compatible readers and keypads:

- NANOPW (White) and NANOPB (Black)
- STARPW (White) and STARPB (Black)
- SOLARPW (White) and SOLARPB (Black)
- DGLP FN WLC26
- DGLP WLC26
- DGLI F WLC26
- DGLI WLC26
- DGLP60WLC
- KCPROXWLC (Reader & Keypad)
- DGLM (Magstripe)
- And most popular Wiegand readers & keypad



For an up-to-date list of which keypads and readers are supported, refer to the ATRIUM Software Manual or visit our web site at www.cdvigroup.com.



Please note that the 2-Door Expander provides 12Vdc output. Connecting a device (keypad or reader) requiring a different voltage may damage the reader or keypad and invalidate the 2-Door Expander warranty.

AX22

2-Door Expander

Connecting Inputs


The 2-Door Expander can monitor the state of up to 20 devices (using zone doubling) such as magnetic contacts, motion detectors, temperature sensors, or other devices. The following are examples of the type of inputs that can be monitored:

Magnetic Door Contact:

Permits supervision of door "status" (opened, closed, opened too long, forced open). Inputs 1 and 6 are assigned by default as the door contact for Door 1 and Door 2 respectively. When using the default system settings, you can easily swap terminals to troubleshoot the installation.

Request to Exit (REX):

The device used can be a push button, vertical-view motion detector or floor mat sensor. The door can then be programmed to unlock on a REX detection. Not required if there is a reader/keypad on both sides of the door. When a magnetic door contact is installed, the system can differentiate between a door forced open and an authorized exit. Inputs 2 and 7 are assigned by default for Door 1 and Door 2 REX inputs respectively.



See "Recommended Wiring" chapter for more information on wiring type, size, and maximum length.


AX22

2-Door Expander

Examples of Input Connection Methods

Single without EOL and without TAMPER Supervision (Limit of 1 Detection Device on the Input)

When using this method, only one device can be connected to the input. The input must be connected using only one Contact (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will not support WIRE CUT or WIRE SHORT supervision, but will generate an alarm condition when the state of the input is breached.




WIRE SHORT supervision: NO

WIRE CUT supervision: NO

Single with WIRE SHORT Supervision (Limit of 1 Detection Device on the Input)

When using this method, only one device can be connected to the input. The input must be connected using only one Contact (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will not support WIRE CUT supervision but offers WIRE SHORT supervision and will generate an alarm condition when the state of the input is breached.




WIRE SHORT supervision: YES (Detected as INPUT SHORT)

WIRE CUT supervision: NO


Single with WIRE CUT Supervision (Limit of 1 Detection Device on the Input)

When using this method, only one device can be connected to the input. The input must be connected using only one Contact (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will support WIRE CUT supervision but will not offer WIRE SHORT supervision and will generate an alarm condition when the state of the input is breached.



WIRE SHORT supervision: NO

WIRE CUT supervision: YES (Detected as INPUT CUT)




AX22

2-Door Expander

Single with WIRE SHORT and WIRE CUT Supervision (Limit of 1 Detection Device on the Input)

When using this method, only one device can be connected to the input. The input must be connected using only one Contact (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will support both WIRE CUT and WIRE SHORT supervision and will generate an alarm condition when the state of the input is breached.




WIRE SHORT supervision: YES (Detected as INPUT SHORT)

WIRE CUT supervision: YES (Detected as INPUT CUT)

Doubled with WIRE CUT Supervision (2 Detection Device on the Input)

When using this method, two device can be connected to the input. The input must be connected using two Contacts (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will support WIRE CUT supervision but not WIRE SHORT supervision and will generate an alarm condition when the state of one of the input is breached.




WIRE SHORT supervision: NO

WIRE CUT supervision: YES (Detected as INPUTS CUT)

Doubled with WIRE SHORT and WIRE CUT Supervision (2 Detection Device on the Input)

When using this method, two device can be connected to the input. The input must be connected using two Contacts (NO or NC: programmable per INPUT in Software) as described in the following figure. This setup will support WIRE CUT and WIRE SHORT supervision and will generate an alarm condition when the state of one of the input is breached.



WIRE SHORT supervision: YES
(Detected as INPUTS SHORT)

WIRE CUT supervision: YES
(Detected as INPUTS CUT)

AX22

2-Door Expander

Door - Locking Devices

Each 2-Door Expander Module has two lock outputs and each of these outputs is associated to a reader input. When the LOCK OUTPUT is configured (see "Jumper Settings" on page 17) to provide power (12Vdc), the LOCK OUTPUT is protected by a fuseless protection monitoring algorithm and will shutdown if the current exceeds 750mA @ 12Vdc. When interconnecting to an alarm system, we recommend to use the LOCK OUTPUT in its DRY CONTACT Configuration (see "LOCK1/LOCK2 Jumper Settings" table).

- If you have one door with a reader on each side of the door, you can use either lock output.
- You can program the lock outputs to function in "fail-safe" (remove power to unlock a door) or "fail-secure" mode (power required to unlock a door).
- When using Electronic Mag Clamps or similar devices ensure that the current specifications are not exceeded.



Always consult the regulatory agency in your area for existing regulations regarding doors designated as emergency exits.

Jumper Settings

The jumpers LOCK1 and LOCK2 must be set according to the door devices used. For a 12Vdc locking device (magnetic or strike), it can be connected to the terminals and the jumpers set in 12Vdc power mode on VLK+. Use either the NO or NC Lock Output Contact depending on the FAIL SAFE or FAIL SECURE connection mode. If the lock (or electromagnetic) requires 24Vdc, the lock output must be used in its dry contact mode and an external 24Vdc power supply must be used. The same applies if the Locking Device requires an alternating current supply (Vac).

LOCK1 / LOCK2 JUMPER SETTING			
LOCK OUTPUT 12V			
LOCK 1 = LA1 & LB1 AND LOCK 2 = LA2 & LB2			
When using ATRIUM internal power supply LA1 & LA2= 12V+ LB1 & LB2= GND	Default		
	DE-ENERGIZED (0V)		ENERGIZED (12V)
	A	Work with	A
	B	"Fail Secure"	B
	C	device	C
DRY CONTACT RELAY			
When Using External Power Supply	A	N.O.	A
	B		B
	C		C
			N.C.


AX22

2-Door Expander

Wiring Diagram of Locking Device


Using On-Board
Power Supply

Lock Outputs:
750mA @ 12Vdc



Using External
Power Supply

Lock Outputs:
750mA @ 12Vdc



See "Recommended Wiring" chapter for more information on wiring type, size, and maximum length.



Terminals EM1 and EM2 are reserved for future use.

AX22

2-Door Expander

Power Connections



Do not power up the 2-Door Expander until all connections are completed.

The module operates from any 120/240 Vac sources using the supplied AC/DC power supply and provides fully monitored power solutions using:

- Smart Battery Deep discharge prevention with automatic electronic cut-off.
- Programmable & Adaptive battery charging algorithm (250mA (default), 320mA, 500mA, or 1A).
- Intelligent battery monitoring & charging algorithms allowing optimum performance using standard lead acid batteries.
- Real Time Monitoring algorithm for 'Battery Low/Disconnect/Reversal' and 'Insufficient Main Power'.


AC Source

The AC to DC power supply is pre-installed in the 2-Door Expander box but needs to be connected to the PCB.

1. Connect the AC/DC power supply output cable to the 2-Door Expander DC Power Supply "+" and "-" terminals. The polarity of the wires is identified as shown in the following picture.



2. Connect the pre-installed green power LED to the 2-Door Expander DC Power Supply "+" and "-" terminals; in parallel with the AC/DC power supply. The red wire goes on the "+" terminal and the white on the "-" terminal. Make sure that all wires are properly inserted and tighten.



See "Recommended Wiring" chapter for more information on wiring type, size, and maximum length.



The Minimum Size Equipment Conductors for the AC mains required are 14 AWG if made of Copper or 12 AWG if made of Aluminium or Copper-Clad Aluminium. Do not use any switch-controlled outlets to power the system. The system is to be connected to a 15A receptacle or circuit.



For PERMANENTLY CONNECTED EQUIPMENT, a readily accessible disconnect device shall be incorporated external to the equipment.



For PLUGGABLE EQUIPMENT, the socket-outlet shall be installed near the equipment and shall be easily accessible.

AX22

2-Door Expander

AC Terminal Fuse



The following steps are only presented in case you need to replace the AC terminal fuse.

1. Disconnect the AC power cord from the power source or for permanent installation, turn off the power breaker¹.

2. Open the AC compartment at the top left to access the fuse holder.

3. Pull out the fuse holder.

4. Replace the fuse using the same fuse type:
250VAC, 2.5 A
Time Lag, Slow Blow
Operating Temperature: -55oC to +125oC.

Permitted replacements:


- a) Littelfuse P/N 021802.5MXP
- b) Schurter P/N 0034.3121
- c) Various (means any type, from any manufacturer that complies with the "Technical Data and securement means" and meets the "Mark of conformity" can be used).

5. Replace the fuse holder in its location.

6. Close the AC compartment.

7. Connect the AC power cord to the power source or for permanent installation, turn on the power breaker¹.

Fuse holder




¹. For permanent installation, this step must be done by a qualified person in accordance with your local safety regulations.

AX22

2-Door Expander

Battery Backup

The 2-Door Expander cannot be started on battery power only. Battery backup time varies with each system. Typical backup time is between 2 and 20 hours using standard equipment and settings. Wire a 12Vdc (either 4.5Ah or 7Ah) gel type battery and then connect it to the BATT "+" and "-" terminals with the battery leads supplied.



12Vdc 7Ah rechargeable acid/lead or gel cell backup battery (UL/ULC: YUASA #NP7-12 recommended, Europe: CDVI B7AH recommended). Ensure proper polarity. Various (means any type, from any manufacturer that complies with the "Technical Data and securement means" and meets the "Mark of conformity" can be used).




The battery charge current can be set to either 250mA (default), 320mA, 500mA, or 1A. Refer to the ATRIUM user interface instruction manual for more information on how to modify the battery charging current.

AX22

2-Door Expander

LED Indicators

The ATRIUM 2-Door Expander has several status LEDs that are very useful to diagnose problems when using or installing the ATRIUM system. Refer to the following picture for the emplacement of those LEDs on the ATRIUM 2-Door Expander. All LEDs are explained in the following pages.



1	READERS	# 1	Green LED flashing: Data received from Reader #1.
		#2	Green LED flashing: Data received from Reader #2.
2	GLOBAL	STAT	Flash once per second: Firmware is operating normally. Flash rapidly: Firmware is upgrading. Blink once per 3 seconds: Card enrollment mode.
		DC IN	DC IN Green LED: 2-Door Expander is powered properly. Red LED: No primary power.
		BATT	BATT Green LED: Primary power present and battery charging. Off LED: Primary power present and battery full. Red LED: No battery or battery not properly connected. Red LED flashing: Battery power is below 11.8Vdc.
		BELL	BELL Red LED: No bell/siren connected or short circuit.
	SUPPLY	AUX (12Vdc supply for readers and inputs connections)	Green LED: Output power activated. Off LED: Deactivated or in protection mode (short circuit).
		VLK1/VLK2	Green LED: Output power activated. Off LED: Deactivated or in protection mode (short circuit).
	LOCAL BUS	RX	Green LED flashing: Data received on local bus.
		TX	Green LED flashing: Data transmitted on local bus.
5	RELAY	LK1	Green LED: Door 1 Lock Relay is active/triggered.
		LK2	Green LED: Door 2 Lock Relay is active/triggered.


AX22

2-Door Expander


Connecting Expander Modules to the Controller

The 2-Door Expander has a RS485 LOCAL BUS terminal allowing the connection with the ATRIUM expander module. Connect the expander module's LOCAL BUS to the ATRIUM 2-Door Expander's LOCAL BUS using star and/or daisy chain topologies. For example:


DAISY CHAIN




BUS



STAR



MIXED DAISY CHAIN/BUS/STAR



AX22

2-Door Expander

6] Warranty - Terms & Conditions

The "Limited Lifetime Warranty" is offered by CDVI exclusively for CDVI products featuring the logo "limited lifetime warranty", and supplied by authorized CDVI dealers participating in the offer. You can obtain the address of the local authorized dealer participating in the offer by contacting CDVI or a local CDVI subsidiary. The "limited lifetime warranty" is only applicable to hidden defects detected during the lifetime of the product, as defined by the CDVI Group (10 years or 200 000 operations - whichever of the two expires first).

The "limited lifetime warranty" conditions shall not modify the sales conditions between CDVI and its customers.

DURATION OF THE OFFER:

- This offer is valid from July 1st 2010; CDVI reserves the right to terminate this offer without prior notice.
- However, any product already registered up to the date of withdrawal of the offer will remain eligible for the "Limited Lifetime Warranty".
- The warranty applies only to the available products mentioned in the above statement.

CONDITIONS :

- Hidden defects are guaranteed for an unlimited shelf life (period of time before use).
- To be eligible for the "limited lifetime warranty", the product must be registered at CDVI within one month of its delivery to the end user, by completing in and returning back the "warranty" form by fax, email or post to the local CDVI subsidiary. This information may also be registered on line at www.cdvigroup.com.
- Only the issue of the "limited lifetime warranty" certificate by CDVI can confirm product registration; CDVI may not be held responsible in the event of loss or non presentation of the form.
- The "limited lifetime warranty" only applies to products installed by a skilled and experienced personal with the necessary trade qualifications to install according to the highest standards, respecting the standards, instructions and guidelines defined by CDVI and according to the maximum recommended specifications.
- To enable CDVI to determine whether a product is eligible to claim for the "limited lifetime warranty", after prior issue of a return of materials authorization number (RMA) by CDVI, the customer must return the product and all of its accessories in the original packaging with a copy of its invoice. The transport fees shall be paid by the customer and the package must be returned to CDVI or to a CDVI authorized repair centre.
- Eligibility for the "limited lifetime warranty" cover must be confirmed by CDVI.
- The "limited lifetime warranty" only covers the replacement or repair of the parts acknowledged as faulty by CDVI.
- CDVI reserves the right to respect its obligation by replacing the product or the parts acknowledged as faulty by a standard part replacement or by a product or new parts, or by an updated or improved version of the product with identical or similar functionalities.
- In respect of the applicable law, CDVI cannot be held responsible for material or immaterial damages caused to goods or to third parties and as a direct or indirect result of the installation, utilization, product faults or poor functioning of a device.
- The "limited lifetime warranty" is non-assignable and non-transferrable; only the person who registered the aforementioned warranty may benefit from the warranty.
- The "limited lifetime warranty" is limited to the eligible product and is strictly limited to the conditions in effect on the date of purchase by the customer.

This image shows a single sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Creator of electronic access solutions



* G 0 3 0 1 F R 0 4 1 2 V 0 1 *



CDVI Group

FRANCE (Headquarter/Siège social)
Phone: +33 (0)1 48 91 01 02
Fax: +33 (0)1 48 91 21 21

All the information contained within this document (photos, drawing, features, specifications and dimensions) could be perceptibly different and can be changed without prior notice.

Toutes les informations mentionnées à titre indicatif sur le présent document (photos, dessins, caractéristiques techniques et dimensions) peuvent varier et sont susceptibles de modifications sans notification préalable.

CDVI

FRANCE + EXPORT
Phone: +33 (0)1 48 91 01 02
Fax: +33 (0)1 48 91 21 21

CDVI AMERICAS

[CANADA - USA]
Phone: +1 (450) 682 7945
Fax: +1 (450) 682 9590

CDVI BENELUX

[BELGIUM - NETHERLAND - LUXEMBOURG]
Phone: +32 (0) 56 73 93 00
Fax: +32 (0) 56 73 93 05

CDVI

SUISSE
Phone: +41 (0)21 882 18 41
Fax: +41 (0)21 882 18 42

CDVI

CHINA
Phone: +86 (0)10 62414516
Fax: +86 (0)10 62414519

CDVI IBÉRICA

[SPAIN - PORTUGAL]
Phone: +34 (0)935 390 966
Fax: +34 (0)935 390 970

CDVI

ITALIA
Phone: +39 0321 90 57 3
Fax: +39 0321 90 80 18

CDVI

MAROC
Phone: +212 (0)5 22 48 09 40
Fax: +212 (0)5 22 48 34 69

CDVI SWEDEN

[SWEDEN - DENMARK - NORWAY - FINLAND]
Phone: +46 (0)31 760 19 30
Fax: +46 (0)31 748 09 30

CDVI UK

[UNITED KINGDOM - IRELAND]
Phone: +44 (0)1628 531300
Fax: +44 (0)1628 531003

DIGIT

FRANCE
Phone: +33 (0)1 41 71 06 85
Fax: +33 (0)1 41 71 06 86