

Panasonic®


Installation Guide

Included Installation Instructions

Network Camera

Model No. **WV-SW396A/WV-SW395A**
Rain wash coating Rain wash coating

WV-SW396/WV-SW395



WV-SW396A

(This illustration represents WV-SW396A.)



Before attempting to connect or operate this product,
please read these instructions carefully and save this manual for future use.

The model number is abbreviated in some descriptions in this manual.
This document is the Installation Guide for use in other countries except Japan.

For Europe

We declare under our sole responsibility that the product to which this declaration relates is in conformity with the standard or other normative document following the provisions of Directive 2004/108/EC.

Wir erklären in alleiniger Verantwortung, daß das Produkt, auf das sich diese Erklärung bezieht, mit der folgenden Norm oder normativen Dokument übereinstimmt. Gemäß den Bestimmungen der Richtlinie 2004/108/EC.

Nous déclarons sous notre propre responsabilité que le produit auquel se réfère la présente déclaration est conforme à la norme spécifiée ou à tout autre document normatif conformément aux dispositions de la directive 2004/108/CE.

Nosotros declaramos bajo nuestra única responsabilidad que el producto a que hace referencia esta declaración está conforme con la norma u otro documento normativo siguiendo las estipulaciones de la directiva 2004/108/CE.

Noi dichiariamo sotto nostra esclusiva responsabilità che il prodotto a cui si riferisce la presente dichiarazione risulta conforme al seguente standard o altro documento normativo conforme alle disposizioni della direttiva 2004/108/CE.

Wij verklaren als enige aansprakelijke, dat het product waarop deze verklaring betrekking heeft, voldoet aan de volgende norm of ander normatief document, overeenkomstig de bepalingen van Richtlijn 2004/108/EC.

Vi erklærer os eneansvarlige for, at dette produkt, som denne deklaration omhandler, er i overensstemmelse med standard eller andre normative dokumenter i følge bestemmelserne i direktiv 2004/108/EC.

Vi deklarerar härmed vårt fulla ansvar för att den produkt till vilken denna deklaration hänvisar är i överensstämmelse med standarddokument eller annat normativt dokument som framställs i direktiv 2004/108/EC.

Ilmoitamme yksinomaisella vastuullamme, että tuote, jota tämä ilmoitus koskee, noudattaa seuraavaa standardia tai muuta ohjeellista asiakirjaa, jotka noudattavat direktiivin 2004/108/EC sääöksiä.

Vi erklærer oss alene ansvarlige for at produktet som denne erklæringen gjelder for, er i overensstemmelse med følgende norm eller andre normgivende dokumenter som følger bestemmelsene i direktiv 2004/108/EC.

WARNING:

- Apparatus shall be connected to a mains socket outlet with a protective earthing connection.
- The mains plug or an appliance coupler shall remain readily operable.
- The apparatus should not be exposed to dripping or splashing and that no objects filled with liquids, such as vases, should be placed on the apparatus.
- All work related to the installation of this product should be made by qualified service personnel or system installers.
- For PERMANENTLY CONNECTED APPARATUS provided neither with an all-pole MAINS SWITCH nor an all-all pole circuit breaker, the installation shall be carried out in accordance with all applicable installation rules.
- The connections should comply with local electrical code.

CAUTION:

- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunlight, fire or the like.
- The network camera is only intended for a connection to an ethernet or PoE network without routing to the outside plant.

This product contains a CR Coin Cell Lithium Battery which contains Perchlorate Material - special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate/

For Canada

CAN ICES-3(A)/NMB-3(A)

For U.S.A

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.



For U.S.A

The model number and serial number of this product may be found on the surface of the unit.

You should note the model number and serial number of this unit in the space provided and retain this book as a permanent record of your purchase to aid identification in the event of theft.

Model No. _____

Serial No. _____



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.

Power disconnection. Unit with or without ON-OFF switches have power supplied to the unit whenever the power cord is inserted into the power source; however, the unit is operational only when the ON-OFF switch is in the ON position. Unplug the power cord to disconnect the main power for all units.

Contents

Important safety instructions.....	4
Limitation of liability.....	5
Disclaimer of warranty.....	5
Preface	5
About notations	5
Main functions	6
About the user manuals	7
System requirements for a PC	7
Trademarks and registered trademarks.....	8
Copyright.....	8
Network security	8
Precautions	9
Precautions for installation.....	13
Major operating controls	15
Insert/remove an SDHC/SD memory card	16
Installations/Connections	18
Initialize the camera.....	29
Configure the network settings	30
Troubleshooting	32
Specifications.....	35
Standard accessories.....	39
Optional accessories	39

Important safety instructions

- 1) Read these instructions.
- 2) Keep these instructions.
- 3) Heed all warnings.
- 4) Follow all instructions.
- 5) Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 6) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 7) Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 8) Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 9) Only use attachments/accessories specified by the manufacturer.
- 10) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



- 11) Unplug this apparatus during lightning storms or when unused for long periods of time.

Limitation of liability

THIS PUBLICATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR NON-INFRINGEMENT OF THE THIRD PARTY'S RIGHT.

THIS PUBLICATION COULD INCLUDE TECHNICAL INACCURACIES OR TYPOGRAPHICAL ERRORS. CHANGES ARE ADDED TO THE INFORMATION HEREIN, AT ANY TIME, FOR THE IMPROVEMENTS OF THIS PUBLICATION AND/OR THE CORRESPONDING PRODUCT (S).

Disclaimer of warranty

IN NO EVENT SHALL Panasonic System Networks Co., Ltd. BE LIABLE TO ANY PARTY OR ANY PERSON, EXCEPT FOR REPLACEMENT OR REASONABLE MAINTENANCE OF THE PRODUCT, FOR THE CASES, INCLUDING BUT NOT LIMITED TO BELOW:

- (1) ANY LOSS OR DAMAGE, INCLUDING WITHOUT LIMITATION, DIRECT OR INDIRECT, SPECIAL, CONSEQUENTIAL OR EXEMPLARY, ARISING OUT OF OR RELATING TO THE PRODUCT;
- (2) ANY INCONVENIENCE, LOSS, OR DAMAGE CAUSED BY INAPPROPRIATE USE OR NEGLIGENT OPERATION OF THE USER;
- (3) ALL MALFUNCTIONS OR TROUBLES FROM UNAUTHORIZED DISASSEMBLE, REPAIR OR MODIFICATION OF THE PRODUCT BY THE USER, REGARDLESS OF THE CAUSE OF THE MALFUNCTION OR TROUBLE;
- (4) INCONVENIENCE OR ANY LOSS ARISING WHEN IMAGES ARE NOT DISPLAYED, DUE TO ANY REASON OR CAUSE INCLUDING ANY FAILURE OR PROBLEM OF THE PRODUCT;
- (5) ANY PROBLEM, CONSEQUENTIAL INCONVENIENCE, OR LOSS OR DAMAGE, ARISING OUT OF THE SYSTEM COMBINED BY THE DEVICES OF THIRD PARTY;
- (6) ANY CLAIM OR ACTION FOR DAMAGES, BROUGHT BY ANY PERSON OR ORGANIZATION BEING A PHOTOGENIC SUBJECT, DUE TO VIOLATION OF PRIVACY WITH THE RESULT OF THAT SURVEILLANCE-CAMERA'S PICTURE, INCLUDING SAVED DATA, FOR SOME REASON, BECOMES PUBLIC OR IS USED FOR ANY PURPOSE;
- (7) LOSS OF REGISTERED DATA CAUSED BY ANY FAILURE.

Preface

The network camera WV-SW396A/WV-SW395A/WV-SW396/WV-SW395 is designed to operate using a PC on a network (10BASE-T/100BASE-TX).

By connecting to a network (LAN) or the Internet, images and audio from the camera can be monitored on a PC via a network.

Note:

- It is necessary to configure the network settings of the PC and its network environment to monitor images from the camera on the PC. It is also necessary to install a web browser on the PC.

About notations

The following notations are used when describing the functions limited for specified models.

The functions without the notations are supported by all models.

SW396A: The functions with this notation are available when using the model WV-SW396A.

SW395A: The functions with this notation are available when using the model WV-SW395A.

SW396: The functions with this notation are available when using the model WV-SW396.

SW395: The functions with this notation are available when using the model WV-SW395.


Main functions

H.264/MPEG-4 and JPEG triple encoding

H.264/MPEG-4 stream and JPEG (MPEG) outputs can be simultaneously provided.

* Either H.264 or MPEG-4 is selectable.

Introduction of Super Dynamic (MEGA Super Dynamic)

( Operating Instructions (included in the CD-ROM))

MEGA Super Dynamic compensates brightness on a pixel-to-pixel basis so that it produces clearer images even if objects have various illumination intensities.

Black & white function

Images will be displayed clear even at night since the camera will be automatically switched from the color mode to the black and white mode under low illumination condition.

Megapixel-compatible lens and high accuracy preset position function

A single camera provides wide area monitoring.

The camera can be installed not only on the ceiling but also on the wall

When using an optional mounting bracket, pendant-type installation on a ceiling or embedded mounting on a wall is available.

Dome cover with rain wash coating

The rain wash coating is a special coating applied to the surface of the dome cover that makes it hard for water droplets to adhere to the dome cover.

* The rain wash coating is only effective against water (rain water) and is not intended to be used to protect the surface of the dome cover from other substances such as oil.


Power over Ethernet Plus function

When connecting with a PoE+ (Power over Ethernet Plus) device, power will be supplied by simply connecting a LAN cable. (IEEE802.3at compliant)

Interactive communication with audio

By using the audio output connector and the microphone in connector, receiving audio from the cameras on a PC and transmitting audio from the PC to the cameras is available.

SDHC/SD memory card slot equipped

It is possible to save H.264 videos and JPEG images on the SDHC/SD memory card manually at an alarm occurrence, during the period of the schedule, or on a web browser. It is also possible to save JPEG images at a network failure occurrence. (Download is possible.) (Recommended SDHC/SD memory card  page 38)

Auto tracking function with a smooth changing between panning, tilting and zoom

It is possible to perform a smooth changing between panning, tilting and zoom.

* The accuracy with the auto tracking function depends on the installation location. Make sure that the installation location is appropriate in advance.

About the user manuals

There are 2 sets of operating instructions for the WV-SW396A, WV-SW395A, WV-SW396, WV-SW395 as follows.

- Installation Guide*: Explains how to install and connect devices, as well as how to connect and configure the network.
- Operating Instructions (included in the CD-ROM): Explains how to perform the settings and how to operate this camera.

Adobe® Reader® is required to read these operating instructions on the provided CD-ROM.

When the Adobe Reader is not installed on the PC, download the latest Adobe Reader from the Adobe web site and install it. "WV-SW396, WV-SW395" or "SW396, SW395" shown in the instructions and illustrations used in these operating instructions indicates the WV-SW396A, WV-SW395A, WV-SW396, WV-SW395.

* English screens are used in these operating instructions.

System requirements for a PC

CPU:	Intel® Core™ 2 Duo 2.4 GHz or faster recommended
Memory:	512 MB or more (A minimum of 1 GB memory is required when using Microsoft® Windows® 7 or Microsoft® Windows Vista®.)
Network interface:	10BASE-T/100BASE-TX 1 port
Audio interface:	Sound card (when using the audio function)
Monitor:	Image capture size: 1024x768 pixels or more Color: 24-bit True color or better
OS:	Microsoft® Windows® 7 Microsoft® Windows Vista® Microsoft® Windows® XP SP3
Web browser:	Windows® Internet Explorer® 9.0 (32-bit) Windows® Internet Explorer® 8.0 (32-bit) Windows® Internet Explorer® 7.0 (32-bit) Microsoft® Internet Explorer® 6.0 SP3
Others:	CD-ROM drive (It is necessary to read the operating instructions and use the software on the provided CD-ROM.) DirectX® 9.0c or later Adobe® Reader® (It is necessary to view the PDF file on the provided CD-ROM.)

Important:

- When using a PC that does not meet the above requirements, displaying of images may become slower or the web browser may become inoperable.
 - Audio may not be heard if a sound card is not installed on a PC. Audio may be interrupted depending on the network environment.
 - Microsoft Windows 7 Starter, Microsoft Windows Vista Starter and Microsoft Windows XP Professional 64-bit Edition are not supported.
 - When using IPv6 for communication, use Microsoft Windows 7 or Microsoft Windows Vista.
-

Note:

- For further information about PC system requirements and precautions for when using Microsoft Windows 7, Microsoft Windows Vista, or Windows Internet Explorer, click "Manual" - "Open" from the supplied CD-ROM and refer to "Notes on Windows® / Internet Explorer® versions".
 - If using Microsoft Windows XP, screen tearing* may occur when the shooting scene drastically changes (for example, while shooting fast-moving subjects or while controlling panning/tilting) due to the GDI restrictions of the OS.
* A phenomenon in which portions of the screen are displayed out of alignment
 - For information on the operation verification of the supported operating systems and web browsers, refer to our web-site at <http://security.panasonic.com/pss/security/support/index.html>.
-

Trademarks and registered trademarks

- Microsoft, Windows, Windows Vista, Internet Explorer, ActiveX, and DirectX are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Microsoft product screen shot(s) reprinted with permission from Microsoft Corporation.
- Intel and Intel Core are trademarks or registered trademarks of Intel Corporation in the United States and other countries.
- Adobe, Acrobat Reader, and Reader are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States and/or other countries.
- SDHC Logo is a trademark of SD-3C, LLC.
- iPad, iPhone, and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.
- Android is a trademark of Google Inc.
- All other trademarks identified herein are the property of their respective owners.

Copyright

Distributing, copying, disassembling, reverse compiling and reverse engineering of the software provided with this product are all expressly prohibited. In addition, exporting any software provided with this product violating export laws is prohibited.

Network security

As you will use this unit connected to a network, your attention is called to the following security risks.

- ① Leakage or theft of information through this unit
- ② Use of this unit for illegal operations by persons with malicious intent
- ③ Interference with or stoppage of this unit by persons with malicious intent

It is your responsibility to take precautions such as those described below to protect yourself against the above network security risks.

- Use this unit in a network secured by a firewall, etc.
- If this unit is connected to a network that includes PCs, make sure that the system is not infected by computer viruses or other malicious entities (using a regularly updated anti-virus program, anti-spyware program, etc.).
- Protect your network against unauthorized access by restricting users to those who log in with an authorized user name and password.
- Apply measures such as user authentication to protect your network against leakage or theft of information, including image data, authentication information (user names and passwords), alarm mail information, FTP server information and DDNS server information.
- After the unit is accessed by the administrator, make sure to close the browser.
- Change the administrator password periodically.
- Do not install the camera in locations where the camera or the cables can be destroyed or damaged by persons with malicious intent.

Precautions

Refer installation work to the dealer.

Installation work requires technique and experiences.
Failure to observe this may cause fire, electric shock, injury, or damage to the product.
Be sure to consult the dealer.

Stop the operation immediately when something is wrong with this product.

When smoke goes up from the product, the smell of smoke comes from the product, or the exterior of the product has deteriorated, continued use will cause a fire or fall of the product resulting in injury, or damage to the product.

Do not attempt to disassemble or modify this product.

Failure to observe this may cause fire or electric shock.
Consult the dealer for the repair or inspections.

Do not insert any foreign objects.

This could permanently damage the product.
Turn the power off immediately and contact qualified service personnel for service.

Select an installation area that can support the total weight.

Selecting an inappropriate installation surface may cause this product to fall down or topple over, resulting in injury.
Installation work shall be started after sufficient reinforcement.

Periodic inspections shall be conducted.

Rust on the metal parts or screws may cause a fall of the product resulting in injury or accidents.
Consult the dealer for the inspections.

Do not use this product in an inflammable atmosphere.

Failure to observe this may cause an explosion resulting in injury.

Avoid installing this bracket in the locations where salt damage occurs or corrosive gas is produced.

Otherwise, the mounting portions will deteriorate and accidents such as a fall of the product may occur.

The measures of protection against a fall of this product shall be taken.

Failure to observe this may cause a drop resulting in injury or accidents.

The exclusively designed mount bracket shall be used.

Failure to observe this may cause a drop resulting in injury or accidents.
Use the exclusively designed mount bracket for installation.

The screws and bolts must be tightened to the specified torque.

Failure to observe this may cause a drop resulting in injury or accidents.

Do not install this product in locations subject to vibration.

Loosening of mounting screws or bolts may cause a fall of the product resulting in injury or accidents.

Do not strike or give a strong shock to this product.

Failure to observe this may cause fire or injury.

Turn the power off when do wiring of this product.

Failure to observe this may cause electric shock. In addition, short circuit or wrong wiring may cause fire.

Do not rub the edges of metal parts with your hand.

Failure to observe this may cause injury.

Do not touch the main body while this product is panning/tilting.

Fingers may be caught up in the moving part, and that may result in injury.

Keep SDHC/SD memory cards (option) away from infants and children.

Otherwise, they may swallow the cards by mistake.
In this case, consult a doctor immediately.

The measures of protection against snowfall shall be taken.

Weight of snow may cause a fall of the product resulting in injury or accidents.
Protect the product against snowfall by installing under eaves.

Install this product in a location high enough to avoid people and objects from bumping the product.

Failure to observe this may cause injury.

Do not hang down from this product or use this product as a pedestal.

Failure to observe this may cause injury or accidents.

Do not touch this product, the power cable or the connected cables during thunder. (Including during installation work)

Failure to observe this may cause electric shock.

Do not damage the power cable.

Do not damage, fabricate, twist, stretch, bundle, or forcibly bend the power cable. Do not place heavy objects. Keep away from heat sources.

Use of the damaged power cable may cause electric shock, short circuit, or fire.

Consult the dealer for repair.

Do not install this product on a place that is greatly influenced by wind.

Installation on a place where the wind speed is 40 m {131.23 feet} or more per second may cause a fall of the product resulting in injury or accidents.

Turn the power off when cleaning this product.

Failure to observe this may cause injury.

[Precautions for use]**This product has no power switch.**

When turning off the power, disconnect the power supply from the 24 V AC power supply or the PoE+ device. When using both the 24 V AC power supply and the PoE+ device for power supply, disconnect both the connections.

To keep on using with stable performance

Do not use this product in hot and humid conditions for a long time. Failure to observe this causes component degradation resulting in life shortening of this product.

Do not expose this product to direct heat sources such as a heater.

Handle this product with care.

Do not drop this product, nor apply shock or vibration to the product. Failure to observe this may cause trouble.

Do not give a strong shock to the dome cover.

It may cause damage or water exposure.

About the PC monitor

When displaying the same image on the PC monitor for a long time, the PC monitor may be damaged.

It is recommended to use a screen-saver.

When an error is detected, this product will restart automatically.

This product will be inoperable for around 2 minutes after the restart just as when the power is turned on.

Product disposal/transfer

Data saved on this product or a storage device used with this product may lead to personal information leakage. When it is necessary to dispose or give this product to someone, even when for repair, make sure that there is no data on this product.

Do not touch the dome cover with your bare hands.

A dirty dome cover causes deterioration of picture quality.

- The rain wash coating is applied to the surface of the dome cover. Do not directly touch the surface of the dome cover or wipe it with a cloth or other product. Failure to observe this may reduce the effectiveness of the rain wash coating. **SW396A** **SW395A**

Cleaning this product body

Be sure to turn off the power before cleaning.

- When cleaning the dome cover, wash away any dirt or other unwanted substances by pouring or spraying clean water from a hose or spray bottle (do not wipe the dome cover with a cloth or other product). **SW396A** **SW395A**

Do not use benzine, thinner, alcohol, or any other types of solvents or detergents.

- When cleaning areas other than the dome cover, do not use benzine, thinner, or any other types of solvents. Failure to observe this may cause discoloration. When using a chemical cloth for cleaning, read the caution provided with the chemical cloth product.

Important:

- Improper cleaning of the dome cover may cause the rain wash coating to become less effective. In this case, in order to have effective rain wash coating, a new dome cover must be purchased to replace the existing dome cover. Consult with your dealer or construction contractor. **SW396A** **SW395A**
 - The camera position may be moved inadvertently while cleaning the camera body. Restart the product or refresh the camera position (position refresh) to correct the camera position. Refer to the Operating Instructions (included in the CD-ROM) for further information.
-

Transmission interval

Image transmission interval may become slow depending on the network environment, PC performance, shooting subject, access number, etc.

When the following message appears on the screen during use

CAUTION:
POWER SUPPLY IS ONLY
INTENDED FOR USE OF
POE+(CLASS4) HUB
-IEEE802.3AT COMPLY
OR
AC24V MIN3.0A CLASS2
SUPPLY

The product may not be connected to a proper power-supply device. Check whether the power supply device in use is compatible with PoE+ (IEEE802.3at compliant). Or use 24 V AC power supply.

What to do if "WARMING UP-PLEASE WAIT" appears on the display.

This message indicates that the temperature inside the camera has become extremely low.

In such a case, wait until the heater unit of the camera raises the internal temperature (for around 2 hours or more in low temperatures below -10 °C {14 °F}), and turn on the power again.

About SDHC/SD memory card

- Before removing the SDHC/SD memory card from the camera, it is necessary to select "Not use" for "SD memory card" first. The recorded data may be corrupted if the SDHC/SD memory card is removed when "Use" is selected for "SD memory card". Refer to page 16 for descriptions of how to insert/remove an SDHC/SD memory card.
- When using an unformatted SDHC/SD memory card, format it using this product. Recorded data on the SDHC/SD memory card will be deleted when formatted. If an unformatted SDHC/SD memory card or an SDHC/SD memory card formatted with other devices is used, this product may not work properly or performance deterioration may be caused. Refer to the Operating Instructions (included in the CD-ROM) for how to format a SDHC/SD memory card.
- When some SDHC/SD memory cards are used with this product, the product may not work properly or performance deterioration may be caused. Use the SDHC/SD memory cards recommended in page 38.

Code label

The code labels (accessory) are required at inquiry for trouble. Use caution not to lose these labels. It is recommended to paste one of the labels onto the CD-ROM case.

About the MOS image sensor

- When continuously shooting a bright light source such as a spotlight, the color filter of the MOS image sensor may have deteriorated and it may cause discoloration. Even when changing the fixed shooting direction after continuously shooting a spotlight for a certain period, the discoloration may remain.
- When shooting fast-moving subjects or performing panning/tilting operations, objects crossing the shooting area may look to be bending askew.

MPEG-4 Visual Patent Portfolio License

This product is licensed under the MPEG-4 Visual Patent Portfolio License for the personal and non-commercial use of a consumer for (i) encoding video in compliance with the MPEG-4 Visual Standard ("MPEG-4 Video") and/or (ii) decoding MPEG-4 Video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed by MPEG LA to provide MPEG-4 Video. No license is granted or shall be implied for any other use. Additional information including that relating to promotional, internal and commercial uses and licensing may be obtained from MPEG LA, LLC. See <http://www.mpegla.com>.

AVC Patent Portfolio License

THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE [HTTP://WWW.MPEGLA.COM](http://WWW.MPEGLA.COM)

About the self-diagnosis function

When this product malfunctions due to exogenous noise, etc. for 30 seconds or more, the product will automatically reset and will return to normal state. When the product is reset, initialization will be carried out as when the power of the product is turned on. When the product repeatedly resets, exogenous noise level around the product may be high and that may cause malfunction. Contact your dealer for instructions.

About the dehumidifying device

This product has dehumidifying device to keep the inside at low moisture level, preventing condensation and quickly dissipating dew if produced.

Dew may be produced depending on the conditions of temperature, humidity, winds, and rain, and it may take time to dehumidify.

Lens and pan/tilt head

If a lens and pan/tilt head are not performed for a long period of time, the grease coating inside these parts may become sticky. That may obstruct the parts from moving. To prevent this, move the lens or pan/tilt head periodically. Or perform position refresh periodically in the manner described in "Position refresh".

Position refresh

During the use for a long period of time, the preset positions may become inaccurate. When "Position refresh" is set for the created schedule, the camera position will be corrected periodically.

Refer to the Operating Instructions (included in the CD-ROM) for how to perform the settings.

Consumable parts

The following are consumables: Replace them in accordance with their lives. Their lives vary depending on use environment and conditions. Lifetime is just an indication when using the camera at +35 °C {95 °F}.

- Lens unit, panning motor, tilting motor, flat cable for tilting: Approx. 3.7 million operations (Approx. 20000 hours)
Cooling fan: Approx. 52000 hours
Flat cable for panning **SW395A** **SW395**: Approx. 3.7 million operations (Approx. 20000 hours)
Slip ring **SW396A** **SW396**: Approx. 3.7 million operations (Approx. 20000 hours)

Indication label

Remove the main sunshield rear cover of this product to refer to the indication label for the equipment classification and power source, etc.

Precautions for installation

Panasonic assumes no responsibility for injuries or property damage resulting from failures arising out of improper installation or operation inconsistent with this documentation.

Power supply

This product has no power switch. Use a power supply device equipped with the ON-OFF switch for servicing. When the power cable of the product is connected to the power supply device, the power will be supplied to the product. When the product is supplied, the product will perform panning, tilting, zooming and focusing. Before cleaning the product, make sure that the power cable is not connected to the main power supply.

Installation area for this product

Select an appropriate place for the installation area (such as a strong wall or ceiling) in your particular environment.

Mounting method for this product

- This product is designed to be used as a pendant mount camera. If the product is mounted on a desk-top or at a slant, it may not work correctly or its life-time may be shortened.
- Mount the product horizontally so that the dome section faces downward.

Ceiling pendant type mount bracket/Wall mount bracket

- When pendant-mounting on a ceiling on a bracket that is locally procured, use the attachment pipe.
- When installing on a wall, use Wall Mount Bracket WV-Q122A (option). When this product and camera mount bracket are mounted on a ceiling or a wall, use the screws described in the following table. The screws that secure the product are not supplied. Prepare them according to the material and strength of the area where the product is to be installed.

<Installing conditions>

Camera	
Weight	Approx. 4.6 kg {10.15 lbs}
Appropriate mount bracket	
Model No.	WV-Q122A
Weight	Approx. 2 kg {4.42 lbs}
Mount type	On wall
Part to be mounted on	a ceiling/wall
Recommended screw	M8
Number of screw	4
Pull-out capacity of a single screw	823 N {185 lbf}

- Ensure that the mounting surface, anchor and screws are sufficiently strong.
- Do not mount the product on a plaster board or a wooden section because they are too weak. If the product is unavoidably mounted on such a section, the section shall be sufficiently reinforced.

Do not place this product in the following places:

- Locations where a chemical agent is used such as a swimming pool
- Locations subject to humidity, dust, steam and oil smoke
- Locations where a radiation, an X-ray, a strong radio wave or a strong magnetic field is generated
- Locations where corrosive gas is produced, locations where it may be damaged by briny air such as sea-shores
- Locations where the temperature is not within the specified range (☞ page 35).
- Locations subject to vibrations (This product is not designed for on-vehicle use.)
- Locations subject to condensation as the result of severe changes in temperature (In case of installing the product in such locations, the dome cover may become foggy or condensation may be caused on the cover.)

Screw tightening

- The screws and bolts must be tightened with an appropriate tightening torque according to the material and strength of the installation area.
- Do not use an impact driver. Use of an impact driver may damage the screws or cause tightening excessively.
- When a screw is tightened, make the screw at a right angle to the surface. After tightening the screws or bolts, perform visual check to ensure tightening is enough and there is no backlash.

Remove the Protection Cover from the dome cover after the installation is complete. **SW396A** **SW395A**

Remove the cover film from the dome section of the dome cover after the installation is complete. **SW396** **SW395**

Be sure to remove this product if it is not in use.

Shielded (STP) LAN cables must be used with this unit to ensure compliance with EMC standards. *

* For Europe

When noise disturbance may happen

Conduct the power distribution work to keep a distance of 1 m {3.28 feet} or more from the 120 V (for U.S. and Canada) or 220 V - 240 V (for Europe and other countries) power line. Or conduct the electric conduit work separately.

Radio disturbance

When this product is used near TV/radio antenna, strong electric field or magnetic field (near a motor, a transformer or a power line), images may be distorted and noise sound may be produced.

Take notice of humidity.

Install this product when the humidity is low. If this product is installed during rainfall or at a high humidity, the inside may be exposed to moisture and the dome cover may become foggy.

Heater unit

This product is equipped with an internal heater unit for use in cold climates. When connected with a PoE+ hub/device, the product can operate in an environment below -30 °C {-22 °F}. When connected with the 24 V AC power supply, the product can operate in an environment below -50 °C {-58 °F}* **SW396A** **SW396** / -40 °C {-40 °F} **SW395A** **SW395**. The heater unit turns on automatically when the temperature inside the product drops below +10 °C {50 °F}. However, in an extremely low-temperature environment below -30 °C {-22 °F}, snow and frost may not be defrosted from the dome cover. When using the product in cold climates, take notice of the ambient and internal temperatures of the product.

When this product is installed and operated in low temperatures below -10 °C {14 °F}, normal images may not be obtained immediately after startup. In such a case, wait around 2 hours or more, and turn on the power again.

* When using this product at temperatures of -40 °C {-40 °F} or below, use the power supply between 24 V AC and 27 V AC. **SW396A** **SW396**

Influence on images and their quality

This product has no wiper unit. Under the following conditions, image quality may deteriorate or images may not be viewed properly.

(1) Influence by rainfall

Due to the wind that accompanies rainfall, images may be less viewable.

(2) Influence by snowfall

Due to the wind that accompanies snowfall, snow may fall on the dome cover. That may partially make surveillance images inviewable. (The extent of inviewability may vary depending on the amount of snowfall and the quality of snow.)

(3) Influence by dust in the air or gas emission from vehicles

Depending on the installation environment, dome cover may be dirty due to dust in the air or gas emission from vehicles. That may degrade the quality of images.

Check before connection

Compatibility of devices are restricted. Before connections, check the ratings and dimensions of the devices to be used.

Contact your dealer for details.

Router

When connecting this product to the Internet, use a broadband router with the port forwarding function (NAT, IP masquerade).

Refer to the Operating Instructions (included in the CD-ROM) for further information about the port forwarding function.

Procure fixing screws separately.

The screws that secure this product are not supplied. Prepare them according to the material and strength of the area where the product is to be installed.

PoE+ (Power over Ethernet Plus)

Use a PoE+ hub/device that is compliant with IEEE802.3at standard.


It is impossible to supply the power to this product from a PoE hub that is compliant with IEEE802.3af standard.

Time & date setting


It is necessary to set the time & date before putting this product into operation. Refer to the Operating Instructions on the provided CD-ROM for descriptions of how to perform the settings.

Major operating controls

<Main body>



<Rear view of the main body with the main sunshield rear cover detached>



Insert/remove an SDHC/SD memory card


How to insert an SDHC/SD memory card

Important:

- When inserting an SDHC/SD memory card, make sure the direction.


Step 1

Pull out the main sunshield rear cover on the rear of the camera by pressing the tab on the top of the sunshield.




Step 2

Remove the locking screw of the water-resistant cap.




Step 3

Turn the water-resistant cap to the "OPEN" side, and pull out the cover.




Step 4

Insert an SDHC/SD memory card into the SDHC/SD memory card slot. Push the memory card straight into the slot until a click is heard.




Step 5

Align "Δ" of the water-resistant cap to "OPEN ▽" of the camera. Then, turn the water-resistant cap toward "▽ LOCK" until the Water-resistant cap is secured to the camera.




Step 6

Secure the water-resistant cap with the locking screw.
(Recommended tightening torque: 0.69 N·m {0.51 lbf·ft})



Step 7

First, insert the tab on the bottom of the main sunshield rear cover into the main body, and then push the tab on the top of the main sunshield rear cover into the main body until a click is heard.



Step 8

Select "Use" for "SD memory card" on the [SD memory card] tab of the "Basic" page on the setup menu. (☞ Operating Instructions (included in the CD-ROM))

Step 9

Format the SDHC/SD memory card by clicking the [Execute] button of "Format" on the [SD memory card] tab of the "Basic" page on the setup menu.
(☞ Operating Instructions (included in the CD-ROM))

How to remove the SDHC/SD memory card

Important:

- Before removing the SDHC/SD memory card, select "Not use" for "SD memory card" on the [SD memory card] tab of "Basic" on the setup menu first. (☞ Operating Instructions (included in the CD-ROM))

Step 1

Remove the water-resistant cap by following steps 1 - 3 of the "How to insert an SDHC/SD memory card" section (☞ page 16).

Step 2

Push the SDHC/SD memory card to release the lock. The SDHC/SD memory card will come up from the slot.

Step 3

Return the parts to the original state by following steps 5 - 7 of the "How to insert an SDHC/SD memory card" section.

Installations/Connections

Caution:

- ONLY CONNECT 24 V AC CLASS 2 POWER SUPPLY (UL 1310/CSA 223) or LIMITED POWER SOURCE (IEC/EN/UL/CSA 60950-1).


Before installation, prepare the following

When mounting this camera, wall mount bracket WV-Q122A (option) is required. When mounting the camera on a bracket that is locally procured, the attachment pipe is required.

Refer to the installation guide of the bracket to be used for details on the installation procedures of the bracket and the camera.

Important:

- When using these mount brackets, the hexagon screws (M6) that are accessory of the brackets cannot be used as the mounting screws for this camera. Use the hexagon screws (M5) attached to the housing base.
- When mounting the camera, remove the 4 hexagon screws (M5), then the attachment pipe from the housing base.




How to detach the housing base

Step 1

Remove the fixing screws (3 pcs.*) that are securing the housing base and the camera.


The removed screws will be required when attaching the housing base to the camera again. Use caution not to lose these screws.

* Special screw (Fixing screw): These screws are hexagon screws. Use an M5 hexagon wrench.



Note:

- If the front and rear sunshields (accessory) are attached to the camera, detach them by performing steps 5 - 7 of "Installation" in the reverse order. (Page 22)



Important:


- Remove the Protection Cover from the camera after the installation is complete. SW396A SW395A

Step 2

To separate the housing base from the camera, turn the housing base to the direction of the arrow as illustrated. (Refer to the illustration in Step 1)

Step 3

Remove the attachment pipe from the upper base by loosening 4 screws.



Installation

Before starting installation/connection, make sure that the power cable is not connected to the main power supply. Refer to the "Precautions for installation" section before starting installation/connection. (Page 13)

Step 1

Install the mounting bracket.

When using the wall mount bracket WV-Q122A (option).


Refer to the installation guide of the bracket (WV-Q122A) for details on the installation procedure.

Take care of the direction to install the mount bracket so that the camera can be mounted at the front of the bracket.

When using the mount bracket (locally procured).

The figure shows an example of the camera mounted on a ceiling with a locally procured bracket.


Refer to the instructions included with the bracket for filling gaps and holes with waterproof material.



Construction


Procure a ceiling mount bracket.

R 1-1/2, 11 crest, deep 30 MAX
(taper pipe thread)




Mounting the Bracket

- ① Fix the bracket to the installation surface using appropriate bolts, nuts or the like (not supplied).



- ② Fix the attachment pipe to the bracket.
- ③ Fill the gap between the bracket and attachment pipe with waterproof material such as silicon clay.



Step 2

Connect the cables to the camera.
Refer to page 24 for how to connect the cables.

Step 3

Insert the SDHC/SD memory card into the SDHC/SD memory card slot.
Refer to page 16 for how to insert the SDHC/SD memory card.

Step 4


Mount the camera on the bracket.

- ① Attach the housing base to the mount bracket using the hexagon screws (M5) attached to the housing base* provided with the mount bracket.


(Recommended tightening torque: 2.45 N·m {1.81 lbf·ft})

The "REAR" mark of the housing base shall be directed to the wire hook section.

* Special screw: These screws are hexagon screws. Use an M5 hexagon wrench.




- ② Make sure that the projection of the plate spring on the upper side of the camera is located on the "START" position. If not, turn the plate clockwise to locate the projection at the "START" position.



- ③ Connect the safety wire (accessory) to the mount bracket. Refer to the operating instructions of the mount bracket for further information about where to connect the safety wire.

Even when not using the optional mounting bracket (WV-Q122A), connect the safety wire near to the camera as shown in the example below.



<Installation example>



- ④ Attach the camera to the housing base. When attaching the camera to the housing base, the positioning pin shall be on the "REAR" side. Make sure that the camera is securely attached to the mount bracket by turning the camera to the direction of the arrow as illustrated. Then, secure the camera to the mount bracket with the screws removed when detaching the housing base. (Recommended tightening torque: 2.45 N·m {1.81 lbf·ft})

* Special screw (Fixing screw): These screws are hexagon screws. Use an M5 hexagon wrench.

<Overhead view>




Step 5


Attach the front and rear sunshields (accessory) to the camera.

- ① Put the fingers on the dents of the front and rear sunshields to detach the hooks. The sunshields will be divided into two parts.


For loss prevention, one side of the front and rear sunshields are linked together with a wire.



- ② Locate the front and rear sunshields to the position that covers the housing base.



- ③ Joint both sides of front and rear sunshields. Joint the hook and dent on the linked side, and then joint the other side.




Important:

- Joint both sides of the front and rear sunshields before fitting in the main sunshield.
 - Do not trap the safety wire inside.
 - The safety wire is designed to support only the weight of the camera when the camera falls.
- Do not put an excessive weight that the safety wire cannot support.

Step 6

Fit the front and rear sunshields in the main sunshield.


Align "▽" of the rear sunshield to "Δ START" of the main sunshield. Then, turn the front and rear sunshields toward "Δ LOCK" until a click is heard.



Step 7

Fix the front and rear sunshields on the camera using the front/rear sunshield fixing screw (accessory).

(Recommended tightening torque: 0.72 N·m {0.53 lbf·ft})



Important:


- When the power of the camera is turned on, the camera will start panning and the position will automatically be initialized.

Note:

- When removing the front and rear sunshields, perform steps 5 - 7 in the reverse order.

Step 8**SW396A****SW395A**


After the installation is completed, remove the tape wrapped around the camera while holding the Protection Cover, and then take off the Protection Cover.



Connection

Caution:

- Before starting connections, make sure that the power connection (24 V AC power cord or LAN cable) is disconnected. Failure to observe this may cause fire, electric shock, injury, or damage to the product.
- A READILY ACCESSIBLE DISCONNECT DEVICE SHALL BE INCORPORATED TO THE EQUIPMENT POWERED BY 24 V AC POWER SUPPLY.



• Power cable

Connect the power cable to the 24 V AC power supply using the 24 V AC power supply connector kit (accessory).

Important:

- The power supply of 24 V AC shall be insulated against 120 V AC (for U.S. and Canada) or 220 V - 240 V AC (for Europe and other countries).
- Do not cut or process the network cable since the power is superimposed when using a PoE+ device for power supply. Besides, do not put an excessive weight on connected sections.


• **24 V AC power supply connector kit (accessory)**

Recommended specification of cable (wire)

Wire size (AWG), stranded wire	#24 (0.22 mm)	#22 (0.33 mm)	#20 (0.52 mm)	#18 (0.83 mm)
Length of cable	20 m {65.62 feet}	30 m {98.43 feet}	45 m {147.64 feet}	75 m {246.06 feet}

Power supply connector housing (accessory)


Pin No.	Signal
1	24 V AC LIVE (Brown)
2	24 V AC NEUTRAL (Blue)
3	Ground (Green/Yellow)
4	Not use



• **How to assemble the power supply connector**

Remove approx. 3 mm {1/8 inches} of the outer jacket of the cable and twist the cable core to prevent the short circuit first.

Insert the tip of the cable into the point A of the contact, and hold the cable using the cable clamp.




Procure either of the following tools for clamping.

Molex manual clamp tool:

57027-5000 (for UL1015), 57026-5000 (for UL1007)

After clamping the contact and the cable, insert the contact properly into the power supply connector housing.



Important:

- Conduct the electric conduit work after processing the power supply connector and making sure that the camera is operating normally.

• **Network cable**

Connect a LAN cable (category 5e or better, STP*) to the network connector.

* For Europe

Important:

- Use all 4 pairs (8 pins) of the LAN cable.
- The maximum cable length is 100 m {328 feet}.
- Make sure that the PoE+ device in use is compliant with IEEE802.3at standard.
- When connecting both of the 24 V AC power supply and the PoE+ device for power supply, 24 V AC will be used for power supply. Depending on PoE+ (or PoE) devices, the power supply indicator may light or the network functions may be unavailable. In this case, disable the PoE+ (or PoE) settings. Refer to the operating instructions of the PoE+ (or PoE) device in use.
- When disconnecting the LAN cable once, reconnect the cable after around 2 seconds. When the cable is quickly connected, the power may not be supplied from the PoE+ device.
- The network camera is only intended for a connection to an ethernet or PoE network without routing to the outside plant.

• **Output cable for the monitor used for adjustment**

Connect a coaxial cable (BNC) (only for checking if images are displayed on the monitor).

This output is provided only for checking the adjustment of the angular field of view on the video monitor when installing the camera or when servicing.

Important:

- The monitor out connector for adjustment is provided only for checking the adjustment of the angular field of view on the video monitor when installing the camera or when servicing. It is not provided for recording/monitoring use.
- Black bands may appear at the top and bottom or right and left of the screen. (That does not affect the adjustment because the angular field of view is not changed.)

• External I/O cable

Important:

- Input and output of the external I/O terminal 2 and 3 can be switched by configuring the setting. The default of EXT I/O terminal 2 is "ALARM IN 2" and of EXT I/O terminal 3 is "ALARM IN 3". It is possible to determine whether or not to receive input from EXT I/O terminal 2 and 3 (ALARM IN2, 3) by selecting "Off", "Alarm input", "Alarm output" or "AUX output" for "Terminal alarm 2" or "Terminal alarm 3" on the [Alarm] tab on the "Alarm" page. Refer to the Operating Instructions (included in the CD-ROM) for further information.
 - When using the EXT I/O terminals as the output terminals, ensure they do not cause signal collision with external signals.
-

<Ratings>

- ALARM IN1/ DAY/NIGHT IN, ALARM IN2, ALARM IN3
Input specification: No-voltage make contact input (4 V - 5 V DC, internally pulled up)
OFF: Open or 4 V - 5 V DC
ON: Make contact with GND (required drive current: 1 mA or more)
- ALARM OUT, AUX OUT
Output specification: Open collector output (maximum applied voltage: 20 V DC)
Open: 4 V - 5 V DC by internal pull-up
Close: Output voltage 1 V DC or less (maximum drive current: 50 mA)

• Microphone/line input cable

Connect a monaural mini plug (ø3.5 mm).

- Input impedance: Approx. 2 k Ω (unbalanced)
- Recommended cable length: 1 m {3.28 feet} or less (for microphone input)
10 m {32.8 feet} or less (for line input)
- Recommended microphone: Plug-in power type (option)
- Supply voltage: 2.5 V \pm 0.5 V
- Recommended sensitivity of microphone: -48 dB \pm 3 dB (0 dB=1 V/Pa, 1 kHz)

Important:

- Connect/disconnect the audio cables and turn on the power of the camera after turning off the power of the audio output devices. Otherwise, loud noise may be heard from the speaker.
-

• Audio output cable

Connect a stereo mini plug (ø3.5 mm). (Audio output is monaural.) Use an external speaker with amplifier.

- Output impedance: Approx. 600 Ω (unbalanced)
- Recommended cable length: 10 m {32.8 feet} or less
- Output level: -20 dBV

Note:

- Make sure that the stereo mini plug is connected to this cable. When a monaural mini plug is connected, audio may not be heard.

When connecting a monaural speaker with amplifier, use an optional conversion cable (mono-stereo).

Connection example


(Refer to page 24 for how to connect the cables.)

When connecting with a PC directly

<Required cable>

LAN cable (category 5e or better, cross, STP*)

* For Europe




When connecting to a network using a PoE+ hub

* When connecting to a network using a PoE+ hub when the temperature is -30°C $\{-22^{\circ}\text{F}\}$ or less, use a 24 V AC power supply.

<Required cable>

LAN cable (category 5e or better, straight, STP*)

* For Europe



Important:

- The video monitor is used for checking the adjustment of the angular field of view when installing the camera or when servicing. It is not provided for recording/monitoring use.
- Depending on the monitor, some characters (camera title, preset ID, etc.) may not be displayed on the screen.
- Use a switching hub or a router which is compliant with 10BASE-T/100BASE-TX or better. (When supplying the power to a hub or router, apply PoE+ (IEEE802.3at compliant).) It is impossible to supply the power to this product from a PoE hub or router that is compliant with IEEE802.3af standard.
- If a PoE+ device (hub) is not used, each network camera must be connected to a power supply.
- When using 24 V AC, power supply from a PoE (or PoE+) hub or router is not required.

Initialize the camera

Use the initial set switch to reset the settings of the camera to the default.

Important:


- The settings including the network settings will be initialized. Note that the preset position settings and the CRT key (SSL encryption key) used for the HTTPS protocol will not be initialized.

Step 1

Open the SDHC/SD memory card slot cover by following steps 1 - 3 of the "How to insert an SDHC/SD memory card" section (page 16).

Step 2

Move the initial set switch to the right (ON).
The factory default is OFF.



Step 3

Move the Initial set switch to the right, and then turn on the power of the camera. The camera will start up and all the settings including the network settings will be initialized. The initialization will be complete when the live indicator stops blinking orange and lights off. Before initializing the settings, it is recommended to write down the settings in advance.

Important:


- Do not turn off the power of the camera during initialization. Otherwise, it may fail to initialize and may cause malfunction.

Step 4

Turn off the power of the camera.

Step 5

Move the Initial set switch to the left (OFF).



Important:

- If the Initial set switch is positioned to the "ON" side, the camera cannot enter the normal operation mode. Be sure to return the Initial set switch to the "OFF" position.

Step 6

Return the parts to the original state by following steps 5 - 7 of the "How to insert an SDHC/SD memory card" section (page 16).

Step 7

Turn on the power of the camera. (Page 13)


- When the power is supplied, the camera will enter the normal operation mode.

Configure the network settings

Configuring the camera so that it can be accessed from a PC

The following are descriptions for when the camera with default settings is configured. If you are using firewall software on your PC, the Setup Program may not be able to find any cameras on your network. Configure the setting of the camera after temporarily invalidating the firewall software. Contact the network administrator or your Internet service provider for information about configuring the settings of the network.


- 1 Insert the provided CD-ROM into the CD-ROM drive of your PC.
 - The License Agreement will be displayed. Read the Agreement and choose “I accept the term in the license agreement”, and click [OK].
 - The launcher window will be displayed. If the launcher window is not displayed, double click the “CDLauncher.exe” file on the CD-ROM.



Note:

- Refer to “Using the CD-ROM” in the Operating Instructions on the provided CD-ROM for further information about CDLauncher.
-

- 2 Click the [Run] button next to [IP Setting Software].
[Panasonic IP Setting] screen will be displayed. Click the [Network Settings] button after selecting the MAC address/IP address of the camera to be configured.
- 3 Select the camera you want to configure, and click [Access Camera].



Note:

- When cameras are displayed in [Panasonic IP Setting] screen, click the camera with same MAC address as the MAC address printed on the camera that you want to configure.
-

- 4** If the installation screen of the viewer software “Network Camera View 4S” is displayed, follow the instructions of the wizard to start the installation. (The viewer software is installed from the camera.)
- The “Live” page will be displayed.
 - If you cannot install the viewer software “Network Camera View 4S” or if images are not displayed, click the [Install] button next to [Viewer Software] on the launcher window to install the software.
 - Perform the [Time & date] settings in the “Setup” - “Basic” page before using the camera.

Note:

- When no image is displayed on the “Live” page, refer to the Troubleshooting in the Operating Instructions on the provided CD-ROM.
 - It is possible to enhance the network security by encrypting the access to cameras using the HTTPS function. Refer to the Operating instructions on the provided CD-ROM for how to configure the HTTPS settings.
 - Click the [Setup] button on the “Live” page, the user authentication window will be displayed. Enter the default user name and password as follows, and log in.
User name: admin
Password: 12345
 - When changing settings related to the network settings, such as connection mode, IP address, and subnet mask, click the [Network Settings] button in [Panasonic IP Setting] screen as shown in step **3**, then change each setting.
 - Due to security enhancements in “IP Setting Software”, “Network settings” of the camera to be configured cannot be changed when around 20 minutes have passed after turning on the power of the camera. (When the effective period is set to “20 min” in the “Easy IP Setup accommodate period”.)
However, settings can be changed after 20 minutes for cameras in the initial set mode.
 - “Network Camera Recorder with Viewer Software Lite” which supports live monitoring and recording images from multiple cameras is available. For further information, refer to our website
(<http://security.panasonic.com/pss/security/support/info.html>).
-

Troubleshooting

Before asking for repairs, check the symptoms with the following table.

Contact your dealer if a problem cannot be solved even after checking and trying the solution in the table or a problem is not described below.

Symptom	Cause/solution	Reference pages
Power is not turned on.	When using a PoE+ device for power supply <ul style="list-style-type: none"> Are the PoE+ (IEEE802.3at compliant) device and the RJ-45 female connector (cable integrated type) connected using a LAN cable (category 5e or better, STP*)? Check whether the connection is appropriately established. * For Europe Depending on the PoE+ device, the power supply will stop when the demanded power exceeds its total power limit for all PoE+ ports. Refer to the operating instructions of the PoE+ device in use. When connecting both of the 24 V AC power supply and the PoE/ PoE+ device for power supply, the network connection may not be established. Turn down the power supply from the PoE/PoE+ device. 	24
		–
		25
	When using AC power supply <ul style="list-style-type: none"> Is the power cable connected firmly to power that meets the required specifications? Check whether the connection is appropriately established. Is the power supply connector housing attached to the camera firmly? Check if it is attached correctly and firmly. 	24 25
The camera does not move to the preset positions accurately.	<ul style="list-style-type: none"> When the preset positions become inaccurate during use, it is possible to correct the positions by executing the position refresh function. In addition, when "Position refresh" is set for the created schedule, the camera position will be corrected periodically. In some situations, reconfigure the preset positions. 	Operating Instructions (included in the CD-ROM)
When the camera is panning/tilting, the camera stops panning/tilting and mechanical noise comes from the camera.	<ul style="list-style-type: none"> The camera position may have become inaccurate. Carry out the refresh position function from the [Default reset] tab of the "Maintenance" page of the setup menu. 	Operating Instructions (included in the CD-ROM)
The camera starts panning unpredictably.	<ul style="list-style-type: none"> This may be caused by noise. Check the exogenous noise level around the camera. 	11
When the power is turned on, the live indicator lights or blinks orange.	<ul style="list-style-type: none"> Is the LAN cable connected appropriately? Connect the LAN cable appropriately. Is the hub or router connected to the camera operating appropriately? Check if the hub or router in use is operating appropriately. Isn't the LAN cable connected to the camera broken? Replace the cable with another one. 	25

Symptom	Cause/solution	Reference pages
Live indicator keeps on blinking orange approx. in 2 seconds intervals.	<ul style="list-style-type: none"> UPnP™ error has occurred since the power is not supplied to the router. Turn on the power of the router. Wait until the connections are established. 	—
	<ul style="list-style-type: none"> An error has occurred during the port update by the UPnP function. If the router in use does not support the UPnP function, perform the port forwarding setting for the router. In addition, deactivate the setting of auto port forwarding for the camera. 	Operating Instructions (included in the CD-ROM)
	<ul style="list-style-type: none"> UPnP function of the router is disabled. Refer to the operating instructions of the router to enable the UPnP function. 	—
Live indicator never lights up.	<ul style="list-style-type: none"> Is "Off" selected for "Indicator" on the "Basic" page? Select "On" or "On(Access)" for the indicator setting. 	Operating Instructions (included in the CD-ROM)
Live indicator keeps on blinking red.	<ul style="list-style-type: none"> The camera may be out of order. Contact your dealer. Refer to our website (http://security.panasonic.com/pss/security/support/info.html) for further information after checking the displayed contents of the "Maintenance" page - the [Status] tab - "Self check" of the setup menu. 	—
Live indicator lights red.	<ul style="list-style-type: none"> Isn't the write protect switch of the inserted SDHC/SD memory card set to "LOCK"? Unlock the write protect switch of the SDHC/SD memory card. Hasn't the inserted SDHC/SD memory card been formatted on a PC? Use an SDHC/SD memory card formatted on the camera. Or install the software to format the SDHC/SD memory card on the PC. Refer to our website (http://security.panasonic.com/pss/security/support/info.html) for further information about the supported software. Isn't the inserted SDHC/SD memory card faulty? Replace the card with a normal one. 	Operating Instructions (included in the CD-ROM)
Audio input contains noise.	<ul style="list-style-type: none"> Check the following. <ul style="list-style-type: none"> Grounding of the camera, a switching hub or peripheral devices are not done. The camera is used near an electrical power line. The camera is used near a device which produces strong magnetic field or radio waves (such as near a TV/radio antenna, a motor of an air conditioning system, a transformer, etc.) <p>When audio input still contains noise even after checking the above possibilities, use a powered microphone or connect audio output with low output impedance.</p>	13

Symptom	Cause/solution	Reference pages
The power cable insulation is damaged.	The power cable and connectors are worn out. This may result in electric shock or a fire. Unplug the power cable from the AC outlet immediately, and refer to qualified service personnel.	—
The power cable, plug and connectors get hot during use.		
The power cable gets hot when bent or stretched.		
It is hard to see images with the camera when there are raindrops on the dome cover. SW396A SW395A	The effectiveness of the rain wash coating may have been reduced. Refer to "Cleaning this product body" in "Precautions for use" and clean the dome cover. If the situation does not improve contact your dealer.	10

About the live indicator

The live indicator will light or blink as follows depending on the camera status.

Operation status		Indicator status
When the power is turned on	Before the network connection is established	Blinks orange
	When the network connection is established	Blinks orange → Blinks green → Lights green
During the standby or connection (Cable is not connected.)		Lights orange
During the standby or connection (Cable is connected.)		Lights green
During the upgrade process		Blinks orange
During the initialization		Blinks orange → Lights off
Port forwarding error caused by the UPnP function		Blinks orange (in 2 seconds intervals (on for 1 second / off for 1 second))
Trouble happening on the camera		Blinks red
Failure in writing data on the SDHC/SD memory card		Lights red

Specifications

• Basic

Power source:	24 V AC or PoE+ (IEEE802.3at compliant)
Power consumption:	SW396A SW396 24 V AC*: 50 Hz/60 Hz: 43 W/1.8 A, PoE+: Approx. 25 W/460 mA (Class 4 device) SW395A SW395 24 V AC*: 50 Hz/60 Hz: 43 W/1.8 A, PoE+: Approx. 24 W/440 mA (Class 4 device) * ONLY CONNECT 24 V AC CLASS 2 POWER SUPPLY (UL 1310/CSA 223) or LIMITED POWER SOURCE (IEC/EN/UL/CSA 60950-1).
Ambient operating temperature:	SW396A SW396 -50 °C to +55 °C {-58 °F to +131 °F} (24 V AC) ^{*1,2} -30 °C to +55 °C {-22 °F to +131 °F} (PoE+) SW395A SW395 -40 °C to +50 °C {-40 °F to +122 °F} (24 V AC) ^{*1} -30 °C to +50 °C {-22 °F to +122 °F} (PoE+)
Ambient operating humidity:	Less than 90 % (no condensation)
Monitor output (for adjustment):	VBS: 1.0 V [p-p]/75 Ω, composite (BNC)
External I/O terminals:	ALARM IN 1/ DAY/NIGHT IN/ ALARM IN 2/ ALARM OUT/ ALARM IN 3/ AUX OUT (x1 each)
Microphone/line input:	ø3.5 mm monaural mini jack Input impedance: Approx. 2 kΩ (unbalanced) Applicable microphone: Plug-in power type Supply voltage: 2.5 V ±0.5 V Input level: Approx. -10 dBV
For microphone input:	ø3.5 mm stereo mini jack (monaural output) • Output impedance: Approx. 600 Ω (unbalanced) • Recommended cable length: 10 m {32.8 feet} or less • Output level: -20 dBV
For line input:	Camera: IP66 (IEC60529) Type 4 (UL50), NEMA 4 compliant SW396A SW396
Audio output:	* Only when installation work specified in this book is properly performed and appropriate waterproof treatment is performed Turns on automatically when the inside temperature drops below 10 °C {50 °F}.
Water resistance:	SW396A SW396 ø229 mm x 344 (H) mm {ø9-1/32 inches x 13-9/16 inches (H)}, diameter of the dome: 150 mm {5-29/32 inches} SW395A SW395 ø229 mm x 325 (H) mm {ø9-1/32 inches x 12-25/32 inches (H)}, diameter of the dome: 150 mm {5-29/32 inches}
Heater unit:	Mass: Main body: Approx. 4.6 kg {10.15 lbs}
Dimensions:	Finish: Main body: Aluminum die cast with glazed melamine coating (Coating color: Natural silver) Sunshields ^{*3} : ASA resin coating (Coating color: Natural silver) Dome cover: Clear polycarbonate resin (Rain wash coating) SW396A SW395A

*1 When using this product without turning the power off. (However, the temperature inside the camera shall be -10 °C {14 °F} or higher.) Perform settings or startup operations when the ambient temperature is -30 °C {-22 °F} or higher.

*2 When using this product at temperatures of -40 °C {-40 °F} or below, use the power supply between 24 V AC and 27 V AC.

*3 It is impossible to remove the main sunshield.

• Camera

Image sensor:	SW396A SW396 1/4type MOS image sensor SW395A SW395 1/3type MOS image sensor
Effective pixels:	Approx. 1.3 megapixels
Scanning area:	SW396A SW396 3.60 mm (H) × 2.70 mm (V) {5/32 inches (H) × 3/32 inches (V)} SW395A SW395 4.80 mm (H) × 3.60 mm (V) {3/16 inches (H) × 5/32 inches (V)}
Scanning system:	Progressive
Minimum illumination:	SW396A SW396 Color: 0.5 lx {0.05 footcandle} (F1.4, Auto slow shutter: Off (1/30 s), AGC: High, SD Off) 0.031 lx {0.0031 footcandle} (F1.4, Auto slow shutter: max. 16/30 s, AGC: High, SD Off)* BW: 0.06 lx {0.006 footcandle} (F1.4, Auto slow shutter: Off (1/30 s), AGC: High) 0.004 lx {0.0004 footcandle} (F1.4, Auto slow shutter: max. 16/30 s, AGC: High)* SW395A SW395 Color: 0.5 lx {0.05 footcandle} (F1.6, Auto slow shutter: Off (1/30 s), AGC: High, SD Off) 0.031 lx {0.0031 footcandle} (F1.6, Auto slow shutter: max. 16/30 s, AGC: High, SD Off)* BW: 0.06 lx {0.006 footcandle} (F1.6, Auto slow shutter: Off (1/30 s), AGC: High) 0.004 lx {0.0004 footcandle} (F1.6, Auto slow shutter: max. 16/30 s, AGC: High)*
Super-Dynamic:	* Converted value On/Off
Dynamic range:	52 dB typ. (Super Dynamic: On)
Face SD:	On/Off
Gain (AGC):	On(Low)/ On(Mid)/ On(High)/ Off
Adaptive black stretch:	On/Off
Back light compensation (BLC):	On/Off
Light control mode setting:	Indoor scene (50 Hz)/ Indoor scene (60 Hz)/ Outdoor scene/ Fix shutter
Shutter speed:	1/30, 3/100, 3/120, 2/100, 2/120, 1/100, 1/120, 1/250, 1/500, 1/1000, 1/2000, 1/4000, 1/10000
Auto slow shutter:	Off (1/30 s), max. 2/30 s, max. 4/30 s, max. 6/30 s, max. 10/30 s, max. 16/30 s
Color/BW:	On/ Off/ AUTO1/ AUTO2/ AUTO3
White balance:	ATW1/ ATW2/ AWC
Digital noise reduction:	High/Low
Image stabilizer:	On/Off
Video analytics	
Face detection*:	On/Off (with the XML notification setting)
Privacy zone:	Gray/Mosaic/Off (up to 8 zones available)
Camera title on screen:	On/Off Up to 20 characters (alphanumeric characters, marks) Character size: Large/ Middle/ Small
Motion Detection (VMD):	On/Off, 4 areas available
Image hold:	On/Off

* To use the "XML notification" and "Face detection" functions, you need to install the extension software.

• Lens

Zoom ratio:	SW396A SW396	36x/72x with Extra Optical Zoom (at VGA)
	SW395A SW395	18x/36x with Extra Optical Zoom (at VGA)
Digital (electronic) zoom:	SW396A SW396	12x (Max 864x combined with Extra Optical Zoom at VGA)
	SW395A SW395	12x (Max 432x combined with Extra Optical Zoom at VGA)
Focal length:	SW396A SW396	3.3 mm - 119.0 mm
	SW395A SW395	4.7 mm - 84.6 mm
Maximum aperture ratio:	SW396A SW396	1:1.4 (WIDE) - 4.8 (TELE)
	SW395A SW395	1:1.6 (WIDE) - 4.6 (TELE)
Focal length:	SW396A SW396	2.0 m - ∞
	SW395A SW395	1.5 m - ∞
Aperture range:	SW396A SW396	F1.4 - 22, Close
	SW395A SW395	F1.6 - 22, Close
Angular field of view:	SW396A SW396	Horizontal: 1.7 ° (TELE) - 60.2 ° (WIDE)
		Vertical: 1.3 ° (TELE) - 46.0 ° (WIDE)
	SW395A SW395	Horizontal: 3.2 ° (TELE) - 55.2 ° (WIDE)
		Vertical: 2.4 ° (TELE) - 42.1 ° (WIDE)

• Panning/tilting platform

Panning range:	SW396A SW396	360 °Endless panning
	SW395A SW395	0 ° - 350 °
Panning speed:	SW396A SW396	Manual: Approx. 0.065 °/s - 120 °/s, Preset: Up to approx. 400 °/s
	SW395A SW395	Manual: Approx. 0.5 °/s - 100 °/s, Preset: Up to approx. 300 °/s
Tilting range:	SW396A SW396	-15 ° - 185 ° (level – downward – level)
		Selectable tilting angle: 10 °/ 5 °/ 3 °/ 0 °/ -3 °/ -5 °/ -10 ° ^{*1} / -15 ° ^{*1}
	SW395A SW395	-30 ° - 90 ° (upward – level – downward)
		Selectable tilting angle: 10 °/ 5 °/ 3 °/ 0 °/ -3 °/ -5 °/ -10 ° ^{*1} / -15 ° ^{*1} / -20 ° ^{*1} / -25 ° ^{*1} / -30 ° ^{*1}
Tilting speed	SW396A SW396	Manual: Approx. 0.065 °/s - 120 °/s, Preset: Up to approx. 400 °/s
	SW395A SW395	Manual: Approx. 0.5 °/s - 100 °/s, Preset: Up to approx. 100 °/s
Number of the preset positions:	SW396A SW396	256
	SW395A SW395	64
Auto mode:	SW396A SW396	Auto pan/ Preset sequence/ Auto track/ Patrol
	SW395A SW395	Auto pan/ Preset sequence/ Auto track
		Self return: 10 s/ 20 s/ 30 s/ 1 min/ 2 min/ 3 min/ 5 min/ 10 min/ 20 min/ 30 min/ 60 min
Pan/Tilt-flip ^{*2} :	SW396A SW396	-
	SW395A SW395	On/Off
Map shot:		360 map-shot/Preset map-shot

*1 The area hidden by the camera housing may increase.

*2 When the zoom ratio is adjusted to the "TELE" side, images will be partially hidden even if the pan/tilt-flip function is activated.

• Network

Network:	10BASE-T/100BASE-TX, RJ45 connector
Resolution:	Aspect ratio: 4:3
	H.264: 1280x960/ 800x600/ VGA(640x480)/ QVGA(320x240), max. 30 fps
	MPEG-4: VGA(640x480)/QVGA(320x240), max. 30 fps
	JPEG (MJPEG): 1280x960/ 800x600/ VGA(640x480)/ QVGA(320x240), max. 30 fps
	Aspect ratio: 16:9
	H.264: 1280x720/ 640x360/ 320x180, max. 30 fps
	JPEG (MJPEG): 1280x720/ 640x360/ 320x180, max. 30 fps
	* MPEG-4 is not supported.

Image compression method* ¹ * ² :	H.264/MPEG-4
	Image quality: Low/ Normal/ Fine Transmission type: Unicast/Multicast Bit rate: (Constant bit rate/ Frame rate/ Best effort/ Advanced VBR*) 64 kbps/ 128 kbps/ 256 kbps/ 384 kbps/ 512 kbps/ 768 kbps/ 1024 kbps/ 1536 kbps/ 2048 kbps/ 3072 kbps/ 4096 kbps/ *8192 kbps/ *Unlimited Frame rate: (Frame rate/ Advanced VBR*) 1 fps/ 3 fps/ 5 fps/ 7.5 fps/ 10 fps/ 12 fps/ 15 fps/ 20 fps/ 30 fps * only in H.264 mode
JPEG (MJPEG)	Image quality: 0 SUPER FINE/ 1 FINE/ 2/ 3/ 4/ 5 NORMAL/ 6/ 7/ 8/ 9 LOW (10 steps: 0-9) Transmission type: PULL/PUSH
Transmission interval:	0.1 fps - 30 fps (JPEG frame rate will be restricted when displaying both JPEG and H.264/MPEG-4 images.)
Audio compression method:	G.726 (ADPCM) 32 kbps/16 kbps G.711 64 kbps
Bandwidth control:	Unlimited/ 64 kbps/ 128 kbps/ 256 kbps/ 384 kbps/ 512 kbps/ 768 kbps/ 1024 kbps/ 2048 kbps/ 4096 kbps/ 8192 kbps
Protocol:	IPv6: TCP/IP, UDP/IP, HTTP, HTTPS, RTP, FTP, SMTP, DNS, NTP, SNMP, DHCPv6 IPv4: TCP/IP, UDP/IP, HTTP, HTTPS, RTSP, RTP, RTP/RTCP, FTP, SMTP, DHCP, DNS, DDNS, NTP, SNMP, UPnP
OS* ³ , * ⁴ :	Microsoft Windows 7 Microsoft Windows Vista Microsoft Windows XP SP3
Browser:	Windows Internet Explorer 9.0 (32-bit) Windows Internet Explorer 8.0 (32-bit) Windows Internet Explorer 7.0 (32-bit) Microsoft Internet Explorer 6.0 SP3
Maximum concurrent access number:	14 (Depends on network conditions)
FTP client:	Alarm image transmission, FTP periodic transmission (When the FTP transmission is failed, backup on an optional SDHC/SD memory card is available.)
Multi-screen:	Up to 16 camera images can be displayed simultaneously on a multi-screen. (Including the camera itself)
Compatible SDHC/ SD memory card (option):	Manufactured by Panasonic (SD speed class 4 or higher) SDHC memory card: 4 GB, 8 GB, 16 GB, 32 GB SD memory card: 2 GB (except miniSD card and microSD card)
Cellular phone compatibility:	JPEG image, panning/tilting/zoom/focus control, AUX control (by access level)
Mobile terminal compatibility (As of January, 2014)* ⁵ :	iPad, iPhone, iPod touch (iOS 4.2.1 or later) Android™ mobile terminals

*¹ Either H.264 or MPEG-4 is selectable.

*² Transmission for 2 streams can be individually set in the same compression method.

*³ For further information about PC system requirements and precautions for when using Microsoft Windows 7, Microsoft Windows Vista, or Windows Internet Explorer, click "Manual" - "Open" from the supplied CD-ROM and refer to "Notes on Windows® / Internet Explorer® versions".

*⁴ When using IPv6 for communication, use Microsoft Windows 7 or Microsoft Windows Vista.

*⁵ For further information about compatible devices, refer to our website
(<http://security.panasonic.com/pss/security/support/info.html>).

Standard accessories

Installation Guide (this document)	1 set
Warranty card	1 set
CD-ROM*1	1 pc.
Code label*2	1 pc.
The following parts are used during installation procedures.	
Front and rear sunshields	1 pc. each
Front/rear sunshield fixing screw	2 pcs. (incl. 1 spare)
8P alarm cable	1 pc.
24 V AC power supply connector kit	1 pc.
(Power supply connector housing: 1 pc., Contact: 3 pcs.)	
Protection Cover*3	1 pc.

*1 The CD-ROM contains the operating instructions and different kinds of tool software programs.


*2 This label may be required for network management. The network administrator shall retain the code label.

*3 The Protection Cover is used when sending the camera for repairs, and when moving or transporting the camera. Keep it for future use.

Optional accessories

Wall Mount Bracket	WV-Q122A
User License Accessory (For MPEG-4)	BB-HCA5A BB-HCA5CE
User License Accessory (For H.264)	BB-HCA8A BB-HCA8CE

Information for Users on Collection and Disposal of Old Equipment and used Batteries



These symbols on the products, packaging, and/or accompanying documents mean that used electrical and electronic products and batteries should not be mixed with general household waste.

For proper treatment, recovery and recycling of old products and used batteries, please take them to applicable collection points, in accordance with your national legislation and the Directives 2002/96/EC and 2006/66/EC.

By disposing of these products and batteries correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products and batteries, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



For business users in the European Union

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

[Information on Disposal in other Countries outside the European Union]

These symbols are only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.



Note for the battery symbol (bottom two symbol examples):

This symbol might be used in combination with a chemical symbol. In this case it complies with the requirement set by the Directive for the chemical involved.

Cd

For U.S. and Canada:

Panasonic System Communications Company of North America, Unit of Panasonic Corporation of North America

www.panasonic.com/business/

For customer support, call 1.800.528.6747

Two Riverfront Plaza, Newark, NJ 07102-5490

Panasonic Canada Inc.

5770 Ambler Drive, Mississauga, Ontario, L4W 2T3 Canada
(905)624-5010

www.panasonic.ca

For Europe and other countries:

Panasonic Corporation

<http://panasonic.net>

Panasonic System Networks Co., Ltd.
Fukuoka, Japan

Authorised Representative in EU:

Panasonic Testing Centre
Panasonic Marketing Europe GmbH
Winsbergring 15, 22525 Hamburg, Germany

