Field Notes

Concord 4 Programming Chart

Tier 2 Menus




PHONES (cont.)
B
A
#▼ ▲✶
PAGER 1
PAGER 2
PAGER 3
PAGER 4
PAGER 5
DOWNLOADER PHONE
Phone Number None (01030)
High Lvl Rpts On Off (01031)
Low Lvl Rpts On Off (01032)
Exception Rpts On Off (01033)
Open/Close Rpts On Off (01034)
Latchkey Rpts On Off (01035)
Streamlining On Off (01036)
Ptn Assignment 1 2 3 4 5 6 (01037)
Phone Number None (01040)
High Lvl Rpts On Off (01041)
Low Lvl Rpts On Off (01042)
Exception Rpts On Off (01043)
Open/Close Rpts On Off (01044)
Latchkey Rpts On Off (01045)
Streamlining On Off (01046)
Ptn Assignment 1 2 3 4 5 6 (01047)
Phone Number None (01050)
High Lvl Rpts On Off (01051)
Low Lvl Rpts On Off (01052)
Exception Rpts On Off (01053)
Open/Close Rpts On Off (01054)
Latchkey Rpts On Off (01055)
Streamlining On Off (01056)
Ptn Assignment 1 2 3 4 5 6 (01057)
Phone Number None (01060)
High Lvl Rpts On Off (01061)
Low Lvl Rpts On Off (01062)
Exception Rpts On Off (01063)
Open/Close Rpts On Off (01064)
Latchkey Rpts On Off (01065)
Streamlining On Off (01066)
Ptn Assignment 1 2 3 4 5 6 (01067)
Phone Number None (01070)
High Lvl Rpts On Off (01071)
Low Lvl Rpts On Off (01072)
Exception Rpts On Off (01073)
Open/Close Rpts On Off (01074)
Latchkey Rpts On Off (01075)
Streamlining On Off (01076)
Ptn Assignment 1 2 3 4 5 6 (01077)
Phone Number None 01090


PHONE OPTIONS
TIMERS
LIGHT CONTROL
GLOBAL
PARTITION
GLOBAL
PARTITION
PARTITION
Phone Test On Off (02000)
Auto Phone Test On Off (02001)
Auto Test Reset On Off (02002)
Comm Failure On Off (02003)
DTMF Dialing On Off (02004)
Dial Abort Delay 30 sec (15-45) (02006)
Cancel Message On Off (02007)
Pager Delay 15 sec (0-30) (02008)
Call Wait Cancel On Off (02009)
Dial Tone Detect On Off (02010)
Local Phone Ctrl On Off (0210 - 0260)
Remote Access On Off (0211 - 0261)
Ring/Hang/Ring On Off (0212 - 0262)
Line Fail Delay None (10-240 sec) (0213—Ptn 1 only)
Toll Saver On Off (0214 - 0264)
Phone Panic On Off (0215 - 0265)
Phone ACC Key # * (0216 - 0266)
Supervisory Time 1:00 - 4:00 (Random) (0300)
RF Tx Timeout 12 hours (2-24) (0302)
Phone Test Freq. 7 days (1-255) (0303)
Next Phone test 7 days (1-255) (0304)
Output Trip Time 4 sec (1-12) (0305)
Activity Timeout 24 hours (1-42) (0306)
Daylight Saving On Off (0307)
Entry Delay 30 sec (30-240) (0310 - 0360)
Exit Delay 60 sec (45-184) (0011 - 0061)
Extended Delay 4 min (1-8) (0312 - 0362)
Siren Timeout 4 min (1-30) (0313 - 0363)
Sleep Time 22:00 (00:00-23:50) (0314 - 0364)
No Usage time none (2-255 min) (0315 - 0365)
Entry Lights None (3-9) (0400 - 0450)
House Code 1B 2C 3D 4E 5F 6G (0401 - 0451)


TOUCHPAD OPTIONS
GLOBAL
PARTITION
Latchkey Zones
None (1-96)
(0500)
Fire Panic
On Off
(0510 - 0560)
Auxiliary Panic
On Off
(0511 - 0561)
Police Panic
On Off
(0512 - 0562)
Keychain TP Arm
On Off
(0513 - 0563)
Star is No Delay
On Off
(0514 - 0564)
REPORTING
GLOBAL
PARTITION
24-Hour Tamper
On Off
(06000)
Antenna Tamper
On Off
(06001)
Buffer Control
On Off
(06002)
Back In Service
On Off
(06003)
Bypass Reports
On Off
(06004)
Low CPU Battery
On Off
(06005)
Battery Restoral
On Off
(06006)
Buffer Full Report
On Off
(06007)
Zone Restorals
On Off
(06008)
Two Trip Error
On Off
(06009)
TP Panic Rpt Fmt
On Off
(06010)
AC Failure
On Off
(06011)
Receiver Failure
On Off
(06012)
RF Low Bat Rpt
Daily Weekly
(06013)
Opening Reports
On Off
(06100 - 06600)
Closing Reports
On Off
(06101 - 06601)
No Activity
On Off
(06102 - 06602)
Duress Option
On Off
(06103 - 06603)
Force Armed
On Off
(06104 - 06604)
Latchkey Format
On Off
(06105 - 06605)
Freeze Alarm
On Off
(06106 - 06606)
Freeze Temp
42 (40-90)
(06107 - 06607)
Alarm Verify
On Off
(06108 - 06608)
System Tamper
On Off
(06109 - 06609)
Report Confirm
On Off
(06111 - 06611)
RF Supv Rpt
Daily Weekly
(06014)
Swinger Limit
1 (1-2)
(06015)
Aux Power Fail
On Off
(06016)
Ground Fault
On Off
(06017)


SIREN OPTIONS
GLOBAL
PARTITION
Immediate Beeps
On Off
(0700)
Disable Trbl Beeps
On Off
(0701)
UL 98 Options
On Off
(0702)
Global Fire
On Off
(0703)
Silent Panic
On Off
(0704)
Siren Verify
On Off
(0710—Ptn 1 only)
SENSORS
LEARN SENSORS
(080)
Sensor Partition
1 2 3 4 5 6
Sensor Group
0
Trip Sensor
n
SENSOR TEXT
(081)
Text for Sensor
n
Sensor n Item 0
0 -
DELETE SENSORS
(082)
Delete Sensor
n
Delete Sensor n
Done
EDIT SENSORS
(083)
Sn P1 Gnn
NC/NO/TP
RF/HW
Sensor Partition
n
Sensor Group
n



ACCESSORY MODULES (cont.)



ACCESSORY MODULES (cont.)



ONBOARD OPTIONS