


Wall Board Adapter

Part Numbers: MWBA1, MWBA-2G

© Panduit Corp. 2004

INSTALLATION INSTRUCTIONS PN99C



Designed for Communication or Data Wiring Applications
USE ONLY WHERE LOCAL CODES PERMIT

NOT INTENDED FOR USE WITH ELECTRONIC WIRING DEVICES

SINGLE GANG ADAPTER (MWBA)

1. Cut a 3.75" (95.3mm) x 2" (50.8mm) hole in the drywall.

DOUBLE GANG ADAPTER (MWBA-2G)

- 1. Cut a 3.81" (96.8mm) x 3.78" (96mm) hole in the drywall.
- 2. Partially thread the mounting tabs. Insert assembly into hole and center.
- 3. Rotate the mounting tabs behind the drywall. Thread the mounting tabs until snug.

Maximum drywall thickness - .75" (19.1mm). Avoid studs.

TEMPLATE FOR SINGLE GANG ADAPTER

TEMPLATE FOR DOUBLE GANG ADAPTER

For Instructions in Local Languages and Technical Support:

www.panduit.com/resources/install_maintain.asp



E-mail: cs@panduit.com

Fax: (708) 444-6993