REV	MCO	DWN	DATE
A	20273316	HUH	06-NOV-09
B	20312381	DHV	19-AUG-11



DETAIL A
SCALE 1.000







CABINET SHOWN ONLY FOR REFERENCE.

NOTES:

1. INSTALL ADAPTER PANELS AS SHOWN.
2. PLACE LABELS AS SHOWN.
3. USE CABLE TIES TO SECURE THE FIBER.
4. TAKE THE ROUTE OF THE FIBER AS REFERENCE.

INFORMATION ON THIS DOCUMENT IS PROPRIETARY TO TE CONNECTIVITY AND SHALL NOT BE USED, COPIED, REPRODUCED OR DISCLOSED IN WHOLE OR IN PART WITHOUT WRITTEN CONSENT OF TE CONNECTIVITY.

TITLE: FDT-SC APC/UPC INSTALLATION DRAWING

ALL DIMS AND TOLERANCES ARE INCHES UNLESS OTHERWISE SPECIFIED .XX:±N/A .XXX:±N/A ANGULAR:±N/A

SIZE: C

DRAWING NUMBER: 1673956

REV: B

DO NOT SCALE DRAWING

ENGR: ERIKA URIOSTEGUI

DWN: HECTOR UREÑO

SHT. 1 OF 1

DIMENSIONS IN INCHES
THIRD ANGLE PROJECTION