

Telescope Fitting

A Pentair Company

Hoffman Enclosures Inc.
 2100 Hoffman Way
 Anoka, MN 55303-1745
 (763) 422-2211 Tel
www.hoffmanonline.com

1. Remove cover screws and cover.
2. Loosen adapter plate and body screws.
3. Slide bottom straight section under adapter plate.
 Wireway must be inserted a minimum of one inch into body.
4. Tighten adapter plate and body screws.
5. Replace cover and cover screws.

Parts List	
1	Screw, 10-32x.25
2	Screw, 10-32x.25
3	Screw, 10-32x.25
4	Cover
5	Adapter Plate
6	Body

