

ETP-PMKT Pole Mounting Kit Installation Instructions

ETP-PMKT Pole Mounting Kit consists of:

- 4 3/4" 1-bolt flared leg brackets (includes bracket, bolt and washer)
- 1 strand of 7' long 3/4" band
- 2 3/4" Buckles

Connecting a Talk-A-Phone Surface Mount to a Post

You will need 2 brackets and 1 buckle to mount a surface mount to a post. Keep or discard the extra brackets and buckle as you wish. For a vertical post, connect one 1-bolt flared leg bracket to each of the pre-drilled holes above and below the central conduit hole in the back of the surface mount box. Each bracket comes with a bolt and washer, which are placed through the pre-drilled holes from within the surface mount.

For a horizontal post, connect the brackets to the pre-drilled holes on the right and left of the central conduit hole in the back of the surface mount box.

Use the enclosed Band and Buckles to fasten the surface mount box to the post. Use the Band-It Tool to fasten the Bands and Buckles. For details of how to use the Band-It tool, see the instructions that came with your tool. The tool is available separately as model ETP-PMKT-TOOL.



Surface Mount Box with flared leg bracket attached

Copyright 2009 Talk-A-Phone Co. All rights reserved.

ETP-PMKT Pole Mounting Kit Installation Instructions

Connecting a Talk-A-Phone Wall Mount to a Post

Connect the Wall Mount to the post before installing your Emergency Phone. Remove the Wall Mount cap. The cap is attached to the wall mount using #10 spanner screws. If you do not have a driver, one is available from Talk-A-Phone as part number 42834D. A hex bit is also available, part number 42834B.

Connect one 1-Bolt Flared Leg Bracket to each of the pre-drilled keyholes above the central conduit holes and to each of the pre-drilled circular holes below the central conduit holes in the back of the ETP-WM wall mounting accessory. Each Bracket comes with a bolt and washer, which are placed through the pre-drilled holes from within the ETP-WM.

Use the enclosed Band and Buckles to fasten the ETP-WM to the post. Use the Band-It Tool to fasten the Bands and Buckles. For details of how to use the Band-It tool, see the instructions that came with your tool. The tool is available separately as model ETP-PMKT-TOOL.