

Installation Instructions

TERAFRAME VERTICAL CABLE MANAGER

Tools Required

10 mm wrench
#2 Phillips screwdriver (optional, for fiber management spools)

Installation Notes

All cabinets can hold up to four cable managers. Estimated cable capacity is calculated on 50% fill of Cat 6a cable.

- 600mm cabinet: 45 cable capacity. Only short cable fingers are available.
- 700mm cabinet: Short cable fingers can hold 175 cables. Long cable fingers can hold 215 cables.
- 800mm cabinet: Short cable fingers can hold 295 cables. Long cable fingers can hold 370 cables.

NOTE: Fiber management spools are available from CPI (P/N 12765-702 and P/N 12765-706). Mounted on the vertical cabling sections, they provide proper cable support, bend radius, slack management, and maintain strength under heavy cable loads.

Parts List

Vertical Cable Manager
3 M6 carriage bolts and nuts

Assembly Sequence

1. Attach the cable manager with three M-6 carriage bolts at the top, middle, and bottom of the mounting rail. The cable manager is permanently attached to the mounting rail and moves as a unit if the mounting rail is relocated.
2. To adjust the cable manager, loosen the bolts and slide the cable manager on the keyhole slots, then retighten the bolts. The cable manager can be adjusted back and forth up to nearly one inch.

