


DOOR BOTTOMS

Applies to the following door bottoms and astragals:

317_N, 317_P, 318_V, 3185_V, 310, 311CIN

Tools Required:



Installation Instructions:

DOOR BOTTOMS:

1. Measure, mark and trim door bottom shoe to full width of door. Trim seal 1/16" longer than trimmed door shoe at each end. Crimp ends to secure insert.
2. Notch both ends to clear stops.
3. Slide door bottom shoe in place and close door. Position so that it makes light even contact with the threshold. Mark door in center of slotted holes.
4. Drill pilot holes in door at marks.
5. Secure door bottom shoe to door with supplied screws. Adjust to ensure light even contact with threshold.

ASTRAGALS & MEETING STILES:

1. Trim lengths equal to door height.
2. Position at meeting stile edge of doors so that seals slightly overlap. Install screws in center of slots.
3. Adjust as required for proper seal, with ease of opening and closing, then tighten screws.