Latches

AL Series latches are adjustable for flat or beveled edge doors. Latches and strikes are furnished in brass, bronze or chrome finishes compatible with lock trim. When ordering separately, specify quantity, part number, and finish. Standard latches shown in bold type.


Latches				
Backset	Faceplate description	Hsg dia	Deadlatch ¹/₂" (13 mm) throw	Springlatch ¹ /2" (13 mm) throw
2 ³ /8" (60 mm)	1" x 2 ^{1/} 4" (25 mm x 57 mm) square corner	^{7/} 8" (22 mm)	11-085	11-068
	1" x 2 ¹ /4" (25 mm x 57 mm) ¹ /4" (6 mm) radius round corner	^{7/8} " (22 mm)	11-088	11-069
	1" (25 mm) circular drive-in (non-UL) 605 and 626 finishes only	" (25 mm)	11-104	11-110
2³/4" (70 mm)	1" x 2 ¹ /4" (25 mm x 57 mm) square corner	^{7/8} " (22 mm)	11-091	11-111
	1 ¹ / ₈ " x 2 ¹ / ₄ " (29 mm x 57 mm) square corner, standard	" (25 mm)	11-096	11-116
	1" x 2 ¹ /4" (25 mm x 57 mm) ¹ /4" (6 mm) radius round corner 605 and 626 finishes only	^{7∕} 8" (22 mm)	11-092	11-112
	1" (25 mm) circular drive-in (non-UL)	" (25 mm)	11-105	11-113
3 ³ /4" (95 mm)	1 ¹ / ₈ " x 2 ¹ / ₄ " (29 mm x 57 mm) square corner	" (25 mm)	11-103	11-118
5" (127 mm)	Backset extension link*	^{7/8} " (22 mm)	41-005*	

*Backset extension link 41-005 must be used with 2³/₈" backset latches.

Long backsets

Backsets 5" require extension links. AL Series locks with long backsets are normally furnished with 1" faceplates and 7/8" housings. Links installed in 1" latch holes require one G506-815 sleeve (order separately) to join latch and link.

Latch front adapter A501-878



square front faceplates for 11/8" wide door preparations. Furnished in black plastic. Order in units of 100 each.

Square corner latches

Round corner latches

Springlatch

Springlatch

Drive-in latches Springlatch

5" extension link 41-005 ß


(add to 2³/8" backset latch)


Sleeve G506-815 (order separately)



Door reinforcement

Reinforcing unit is required to reinforce and help prevent the collapse of hollow metal doors when locksets are tightly mounted. This kit should be used with long backsets for lateral movement of the latchbolt. Specify door thickness, 1³/₈"





Deadlatch

Deadlatch

