




FIBERRUNNER to FIBERRUNNER Reducer and Transition Fittings



PANDUIT Part Numbers: FRRF4FD2, FRRF6FR4, FRT12X4W4, FRFWC12X4W4, FRRF126, FRT12X4W6, FRFWC12X4W6, FRY126, FRRF126L, FRRF126R, FRRF2412, FRT24X4W12, FRFWC24X12W12, FRRF6FR4SC, FRTSC12W4, FRFWCSC12W4, FRTSC12W6, FRFWCSC12W6, FRRF126SC, FRRF126LSC, FRRF126RSC, FRY126SC

INSTALLATION INSTRUCTIONS



© PANDUIT Corp. 2001





FIBERRUNNER 4x4 to FIBERRUNNER 2x2 Reducer




FIBERRUNNER 6x4 to FIBERRUNNER 4x4 Reducer



FIBERRUNNER 12x4 Horizontal Tee with 4" Exit





FIBERRUNNER 12x4 Four-Way Cross with 4" Exits





For Technical Assistance, Call: 800-777-3300

INSTALLATION INSTRUCTIONS



FIBERRUNNER 12x4 to FIBERRUNNER 6x4 Reducer





FIBERRUNNER 12x4 Horizontal Tee with 6" Exit





FIBERRUNNER 12x4 Four-Way Cross with 6" Exits




FIBERRUNNER 12x4 "Y" Transition with 6" Exits



FIBERRUNNER 12x4 Transition Left with 6" Exit





INSTALLATION INSTRUCTIONS





FRRF126R

FIBERRUNNER 12x4 Transition Right with 6" Exit





FRRF2412

FIBERRUNNER 24x4 to FIBERRUNNER 12x4 Reducer




FRT24X4W12

FIBERRUNNER 24x4 Horizontal Tee with 12" Exit




FRFWC24X4W12


FIBERRUNNER 24x4 Four-Way Cross with 12" Exit




INSTALLATION INSTRUCTIONS




FRRF6FR4SC
(split cover for FRRF6FR4)




FRTSC12W4
(split cover for FRT12X4W4)




FRFWCSC12W4
(split cover for FRFWC12X4W4)




FRTSC12W6
(split cover for FRT12X4W6)




FRFWCSC12W6
(split cover for FRFWC12X4W6)




FRRF126SC
(split cover for FRRF126)




FRRF126LSC
(split cover for FRRF126L)




FRRF126RSC
(split cover for FRRF126R)




FRY126SC
(split cover for FRY126)



FRRF2412CV
(cover for FRRF2412)



FRTCVCV24W12
(cover for FRT24X4W12)



FRFWCCV24W12
(cover for FRFWC24X4W12)

Instruction Sheet RW138B

WORLDWIDE SUBSIDIARIES AND SALES OFFICES

17301 Ridgeland Avenue
Tinley Park, IL 60477-3901
Web Site: www.panduit.com



RACEWAY SYSTEMS DIVISION

Fax: 708-532-1811
Technical Support: 800-777-3300
E-mail: cs@panduit.com