


HORIZONTAL MANAGER, **UNIV,19"W**

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.



To gain access to the cables within the panel, the cover can be hinged open from the top or bottom, or it can be completely removed.

1. With your right hand, grasp the right hinges with your thumb and index finger. Grasp the left hinges with your left hand.

TO HINGE THE COVER OPEN:

2. Pull on either the top or bottom hinges, allowing the cover to pivot on the opposite hinges.

TO REMOVE THE COVER:

3. Pull on all the hinges evenly until they release.