

Horizontal Cable Managers — **Installation**


AR8612, AR8603A, AR8605, AR8606, AR8600A, AR8602A

Inventory


Horizontal Cable Managers

	6 Inch (152.4 mm) Deep	4 Inch (101.6 mm) Deep
1U	AR8612	AR8602A
2 U	AR8606 AR8603A	AR8600A
3U	AR8605	


Hardware



Tools required (not provided)



How to install and remove caged nuts




To install a cage nut:

- 1. From the inside of the enclosure insert the cage nut into the square hole by hooking a tab from one side of the cage nut onto one side of the opening.
- 2. Place the cage nut tool onto the tab on the opposite side of the cage nut and pull to snap it into position.

To remove a caged nut:


1. Squeeze the tabs together to release.




Installation


Adjust the vertical mounting rails

Adjust the depth of the vertical mounting rails, if needed, for non-networking enclosures.







Install the Horizontal Cable Manager




Installing back-to-back Horizontal Cable Managers




Cover Operation



Accessories (not provided)



Cable retainer AR8621



Side channel cable trough AR8016ABLK, AR8008BLK