



INSTALLATION AND OPERATION MANUAL

FVT/FVR40SFP

4-CHANNEL DIGITALLY ENCODED VIDEO USING SMALL FORM-FACTOR PLUGGABLE (SFP) OPTICAL DEVICES

The FVT/FVR40SFP series optical video link provides transmission of four 10-bit medium-haul quality digitally encoded video channels through a selectable small form factor pluggable module (SFP). See instructions included with SFP for installation of selected module.

Bi-color (Red/Green) LED indicators are provided for confirming operating status. See **Figure 4** on **Page 3** for LED indication explanations.

These units are interchangeable between stand-alone or card mount configurations. See **Figure A** on **Page 4** for mounting instructions.

FIGURE 1 – FVT/FVR40SFP TRANSMITTER AND RECEIVER





FIGURE 2 – FVT40SFP TRANSMITTER

FIGURE 3 – FVR40SFP RECEIVER



INS_FVT/FVR40SFP_REV-05/07/10 PAGE 2

FIGURE 4 – LED INDICATORS

	LINK	VIDEO	POWER
GREEN	Communication link has been established over optical fiber	An active video signal is present on the BNC connector.	Unit powered up
RED	Communication link has not been established.	No Video Signal	-
OFF	Not powered up correctly	-	Unit powered down

MECHANICAL INSTALLATION INSTRUCTIONS

INSTALLATION CONSIDERATIONS

This fiber-optic link is supplied as a Standalone/Rack module. Units should be installed in dry locations protected from extremes of temperature and humidity.

C1-US, C1-EU, C1-AU OR C1-CH CARD CAGE RACKS

CAUTION: Although the units are hot-swappable and may be installed without turning power off to the rack, ComNet recommends that the power supply be turned off and that the rack power supply is disconnected from any power source. **Note:** Remove electrical connector before installing in card cage rack.

 Make sure that the card is oriented right side up, and slide it into the card guides in the rack until the edge connector at the back of the card seats in the corresponding slot in the rack's connector panel. Seating may require thumb pressure on the top and bottom of the card's front panel.

CAUTION: Take care not to press on any of the LEDs.

Tighten the two thumb screws on the card until the front panel of the card is seated against the front of the rack.


WARNING: Unit is to be used with a Listed Class 2 or LPS power supply rated 9-12 VDC @ 1A.

IMPORTANT SAFEGUARDS:

- A) Elevated Operating Ambient If installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment may be greater than room ambient. Therefore, consideration should be given to installing the equipment in an environment compatible with the maximum ambient temperature (Tma) specified by the manufacturer.
- B) Reduced Air Flow Installation of the equipment in a rack should be such that the amount of air flow required for safe operation of the equipment is not compromised.

FIGURE A

Dimensions are for a standard ComNet[™] one slot module







3 CORPORATE DRIVE | DANBURY, CT 06810 | USA T: 83.796.5300 | F: 83.796.5303 | TECH SUPPORT: 1.888.678.9427 | INFO@COMNET.NET

8 TURNBERRY PARK ROAD | GILDERSOME | MORLEY | LEEDS, UK LS27 7LE T: +44 (0)113 307 6400 | F: +44 (0)113 253 7462 | INFO-EUROPE@COMNET.NET

> INS_FVT/FVR40SFP_REV-05/07/10 LLC. PAGE 4