

**Order No. 9137420E**

Name External RFID card reader (USB)

- Desc.**
- External RFID card reader
 - for connection to PC via USB interface
 - suitable for management of system and addition of cards via PC application 2N® Helios IP Manager
 - reads EM4100, EM4102 cards

**Order No. 9137430E**

Name 2N® Helios IP card reader

- Desc.**
- internal RFID card reader
 - for fitting in 2N® Helios IP Vario basic module
 - reads cards EM4100, EM4102 and HID Proximity, 125kHz
 - another two switches and Wiegand interface
 - compatible with all 2N® Helios IP Vario models

**Order No. 9151011**

Name 2N® Helios IP card reader + protective switch (only for 2N® Helios IP Force)

- Desc.**
- internal RFID card reader
 - for fitting in 2N® Helios IP Force
 - reads cards EM4100, EM4102 and HID Proximity, 125kHz
 - another two switches and Wiegand interface
 - compatible with 9151102xR 2N® Helios IP Force 2 buttons and readiness for reader

**Order No. 9159030**

Name External RFID card reader

- Desc.**
- secondary reader for connection to internal reader
 - allows control of entry by card from both sides of door
 - cover IP67
 - also suitable for exterior
 - reads EM4100, EM4102 cards

**Order No. 9134165E**

Name Chip card

- Desc.**
- contactless card for access system
 - Type EM4100

**Order No. 9134166E**

Name Chip key ring

- Desc.**
- contactless key ring for access system
 - Type EM4100

**Order No. 9151016**

Name 2N® Helios IP RFID card reader 13 MHz

- Desc.**
- internal RFID card reader for fitting in 2N® Helios IP Force
 - reads cards Mifare, iClass, DESFire and other standards
 - another two switches, logical inputs and Wiegand module
 - compatible with 2N® Helios IP Force 2 buttons and pictograms
 - contains protective switch

