



AC.PB10.F.SS

Exit Push Button



Overview

Schlage pushbuttons are used to control the ingress or egress of a door. The AC.PB10 pushbuttons are easy to install. Schlage entry level pushbuttons are designed to meet commercial applications. Use with indoor swinging or sliding doors that are electrically or electronically locked. Pushbuttons are available for single gang and narrow stile applications.

Features & Benefits

- Single gang exit switch
- Flush vandal resistant
- Screen printed 'PRESS TO EXIT'
- Normally open / Normally closed contacts
- Satin stainless steel finish
- For indoor use
- Supply Voltage: 12/24V DC
- Flush mounted with green plastic domed button

Anixter Part Number: 10016742

About Allegion

Allegion (NYSE: ALLE) is a global pioneer in seamless access, with leading brands like CISA®, Interflex®, LCN®, Schlage®, SimonsVoss® and Von Duprin®. Focusing on security around the door and adjacent areas, Allegion secures people and assets with a range of solutions for homes, businesses, schools and institutions. Allegion had \$2.7 billion in revenue in 2018, and sells products in almost 130 countries. For more, visit www.allegion.com/mea

