

Base/plinth

Base/plinth system VX

Base/plinth corner pieces with base/plinth trim panels, front and rear

Sheet steel

for VX, VX IT, VX SE, TE, TopConsole, one-piece console, PC, IW

High-load capacity base/plinth corner pieces with moulded self-positioning to the enclosure, may be used with or without trim panels depending on the application. Large openings in the corner piece for optimum access to the screw-fastening point, may be concealed with a plastic corner and baying cover.

Material:

- Base/plinth corner piece: Sheet steel
- Base/plinth trim panel, front/rear: Sheet steel
- Corner and baying cover: Plastic

Colour:

- RAL 9005

100 mm high supply includes:

- 4 base/plinth corner pieces, 100 mm high
- 4 corner covers
- 1 baying cover
- 2 base/plinth trim panels, front/rear, 100 mm high
- Assembly parts

200 mm high supply includes:

- 4 base/plinth corner pieces, 200 mm high
- 4 corner covers
- 1 baying cover
- 1 base/plinth trim panel, front/rear, 200 mm high
- 2 base/plinth trim panels, front/rear, 100 mm high
- Assembly parts

100 mm high

For enclosure width mm	Model No.
300	8640.000
400	8640.001
600	8640.002
800	8640.003
850	8640.004
1000	8640.005
1100	8640.006
1200	8640.007
1600	8640.008
1800	8640.009

200 mm high

For enclosure width mm	Model No.
300	8640.020
400	8640.021
600	8640.022
800	8640.023
1000	8640.024
1200	8640.025
1600	8640.026
1800	8640.027



Also required:

- Base/plinth trim panels, sides, to finish off a unit, for additional stabilisation between base/plinths, or for interior configuration, see page 882



Accessories:

- Base/plinth trim panels with brush strip, see page 882
- Base/plinth trim panels, vented, see page 883
- Base/plinth installation bracket, see page 885
- Levelling component for base/plinth, see page 886
- Base mounting plate, see page 885
- Base/plinth adaptor for twin castors and levelling feet, see page 893
- Baying bracket, internal, see page 912
- Transport castors for base/plinth VX, see page 884
- C rails, see page 996

