TITLE

# BEZEL PATCH PANEL
INSTRUCTION SHEET

1. Pull wires through first bezel.
   Place module with face down into
   the second bezel and terminate per
   wiring and cabling instructions.
   Snap module into first bezel.

2. Repeat step 1 until all but the last
   module is wired.

3. The last step is to pull the wires through
   the last bezel and place module as
   shown. Terminate module and snap
   into bezel.

4. Follow up with proper wire management
   for back of panel.

5. After terminating cables to modules,
   dress cables to shelf of panel.

7. Use slots in panel (for either Hook-Loop
   or Tie Wraps) to secure cables to shelf.

8. Cables may be routed from both sides of
   relay rack rather than from just one side.

9. Minimum cable bend radius is 4 times
   the outside cable diameter.

STEP #1

STEP #2

LAST STEP

SIDE VIEW

HOOK-LOOP
SLOT

TOP VIEW

DETAIL OF HOOK-LOOP SLOT

HOOK-LOOP or TIE WRAP

CAD: 716004301

INSTRUCTION SHEET #	REV.	ECN #	SHEET	DWN.BY:	DATE	CHK.BY:	DATE	APP.BY:	DATE
71600430	02	02142	1 of 1	LEVESQUE	06/13/02				