



Online Help

StruxureWare Central

Version 7.0.0

StruxureWare Central Virtual Appliance

The StruxureWare Central 7.0 server is now available as a virtual appliance, supported on VMware ESXi 4.1.0. The full-featured demo of the virtual appliance monitors up to five device nodes and one surveillance node. You can purchase a license key to upgrade to a production version to monitor additional device nodes and activate supported applications, or to migrate from a StruxureWare Central server hardware version to a StruxureWare Central virtual appliance.

Note: VMware ESXi 4.1.0 was used as the reference virtualization platform during the development of the StruxureWare Central 7.0 virtual appliance, and is the first supported virtualization platform. The StruxureWare Central virtual appliance is delivered as an OVA (Open Virtualization Archive), expected to function properly on any virtualization platform that supports this format, or has an appropriate converter utility.

To use the full-featured demo version of the StruxureWare Central virtual appliance, you download the *.ova file from the APC web site, and deploy it to your virtualization platform using the default hardware configuration. For more information, see StruxureWare Central virtual appliance equivalent configurations.

The demo version monitors a maximum of five device nodes and one surveillance node by default. To monitor 25 device nodes, add license keys to monitor additional nodes, or activate supported applications, you must upgrade the StruxureWare Central virtual appliance demo to the production version.

Note: You can add an additional network adapter to enable private networking, or add additional hard disks to increase storage, after the OVA template is deployed.

To upgrade the demo to the production version, you must purchase and apply a production license key, available on the APC web site. To monitor additional device nodes or activate supported applications, you must purchase and apply node license keys and application license keys for the virtual appliance.

To migrate a StruxureWare Central hardware server to a virtual appliance, you must purchase and apply a production license key, and contact APC Support for new node license keys and application license keys for the virtual appliance. To receive these keys, you are required to provide a unique MAC address and serial number for the StruxureWare Central virtual appliance, and for the StruxureWare Central hardware server you are replacing.

A unique serial number is generated for the StruxureWare Central virtual appliance at startup. It is displayed in the "About StruxureWare Central" display, accessed from the **Help** menu.

Note: The serial number for a StruxureWare Central hardware server appears only on its serial number sticker.

A printable document is available on the APC web site that fully describes deploying the StruxureWare Central virtual appliance, and the upgrade and migration processes, including how to purchase and apply the production license.

Deploying and configuring a StruxureWare Central virtual appliance

The StruxureWare Central virtual appliance demo version monitors up to five device nodes and one surveillance node. You can upgrade to a production version after the OVA is deployed.

1. Download the *.ova file from the APC web site.
2. In your virtualization platform client interface, browse to the location of the *.ova file, and load the OVA. This may take several minutes.

Alternatively, you may have the option to specify the URL for the *.ova file in your virtualization environment client interface.

3. Follow the prompts to accept the end user license agreement, and respond to options required to configure the OVA.

Select thin provisioned disk format to allocate storage space on demand. Select thick provisioned disk format to allocate all storage space immediately.

Configuring the network settings

You must provide the MAC Address, IP Address, hostname, and network settings before using the StruxureWare Central virtual appliance.

1. Select the StruxureWare Central virtual appliance you created, and select the option to edit the virtual machine settings.
2. Specify the MAC Address for the virtual appliance manually.

A unique MAC Address is required for each StruxureWare Central . If the MAC Address originally assigned to the virtual appliance is changed, an error will occur on the primary interface, and the virtual appliance will not start.

3. Power on the virtual appliance.
4. In the console view, login to the virtual appliance using `apcsetup` as the username and password.
5. Within five seconds, press `m` to modify the settings.
6. Follow the prompts to specify the IP Address, hostname, subnet mask, and DNS servers for the virtual appliance.
7. After the virtual appliance has restarted, type its IP Address or hostname into a browser to login to the StruxureWare Central client.

Adding an additional network adapter

You can add one additional network adapter to enable private networking. You cannot remove a network adapter once it has been added.

1. Gracefully shut down the virtual appliance.
2. Select the StruxureWare Central virtual appliance, and select the option to edit the virtual machine settings.
3. Select the options to add an ethernet adapter.
4. Specify the type and the network connection.

Ensure this connection is mapped correctly, particularly when the DHCP server will be enabled on the private network interface.

5. Power on the virtual appliance.
6. In the console view, login to the virtual appliance using `apcsetup` as the username and password.
7. Within five seconds, press `m` to modify the settings.
8. Accept the settings you configured previously, or modify settings if needed.
9. Press `y` to accept the **Enable private network interface** option.
10. Specify whether you want to enable the DHCP server on the private network interface.

Upgrading a StruxureWare Central virtual appliance demo version to production

To upgrade from the demo to the StruxureWare Central virtual appliance production version, you must install the production VM license.

1. Purchase the production license key for the virtual appliance.
2. Login to the StruxureWare Central client. In the "License Keys" display, accessed from the **Server Administration Settings** option in the **System** menu, and apply the production license key.
3. Apply the new virtual appliance node license keys and application license keys you received from APC Support.

The upgrade is complete once you have applied the license and application keys. If you want to modify the virtual appliance settings, continue to Step 4.

4. In your virtualization platform client, gracefully shut down the StruxureWare Central virtual appliance.
5. Select the option to edit the StruxureWare Central virtual appliance settings.
6. Modify the hardware, if necessary.

See help for Deploying and configuring a StruxureWare Central virtual server, and StruxureWare Central virtual server equivalent configurations.

7. Power on the virtual appliance.

Migrating a StruxureWare Central hardware server to a virtual appliance

To migrate a StruxureWare Central hardware server to a virtual appliance, you must purchase and apply a production license key. Additionally, you must contact APC Support for new node license keys and application license keys for the virtual appliance.

A printable document that fully describes the migration process, including how to purchase and apply the production license, is available on the APC web site.

1. Perform a back up of the StruxureWare Central hardware server, using the **Server Backup/Restore** option, accessed from the **Server Administration Settings** option in the **System** menu.
2. Deploy the demo version OVA, and configure it using the hardware equivalents for the StruxureWare Central Basic, Standard, or Enterprise server from which you are migrating. **The available disk space for the virtual appliance must be greater than the disk space used by the hardware server.**

You cannot restore to a virtual appliance with fewer CPU, fewer network adapters, less RAM, or less available disk space than the hardware server.

See help for Deploying and configuring a StruxureWare Central virtual appliance, and StruxureWare Central virtual appliance equivalent configurations.

3. Perform a restore on the virtual appliance, using the **Server Backup/Restore** option, accessed from the **Server Administration Settings** option in the **System** menu.

You cannot restore to a virtual machine other than the StruxureWare Central virtual appliance.

4. Apply the production license key to the virtual appliance.
5. Login to the StruxureWare Central client. In the "License Keys" display, accessed from the **Server Administration Settings** option in the **System** menu, apply the new node license keys and application license keys you received from APC Support.

Adding disk space to a virtual appliance

To increase storage for the virtual appliance, you must create additional hard disks.

You cannot change the size of an existing hard disk, or remove a hard disk once it has been created. An error will occur on the primary interface, and the StruxureWare Central virtual appliance will not start.

1. Gracefully shut down the virtual appliance.
2. In your virtual server console, select the option to add a hard disk.
3. Choose the hard disk size.

See StruxureWare Central virtual server equivalent configurations.

4. Choose thin or thick provisioning.
5. Power on the virtual appliance.

Changes in the disk space will take effect once the StruxureWare Central virtual appliance has restarted. Do not shut down the virtual appliance while the disk reconfiguration process is running.

The "Storage Settings" display, accessed from the **Server Administration Settings** option in the **System** menu, shows the total storage space available for the virtual appliance, not the individual hard disks.

Note: To store large amounts of surveillance data, using a remote repository is recommended.

About changing hardware resource settings for the StruxureWare Central virtual appliance

After you have deployed the OVA, you can make changes to the StruxureWare Central virtual appliance settings from your virtualization platform client interface. You use `apcsetup` as the username and password.

Network settings: You can configure an additional network adapter to enable the private network (APC LAN) as the `apcsetup` user or through the StruxureWare Central client.

MAC Address settings: A unique MAC address is required for each StruxureWare Central virtual appliance. If the MAC address originally assigned to the primary or secondary network interface is changed, an error will occur on the primary interface, and the virtual appliance will not start. A message will be displayed indicating the MAC address expected before normal startup will be allowed.

Hard disk settings: To increase storage for the virtual appliance, you can create additional hard disks. You cannot change the size of an existing hard disk, or remove a hard disk once it has been created. An error will occur on the primary interface, and the StruxureWare Central virtual appliance will not start.

Changes in the disk space will take effect once the StruxureWare Central virtual appliance has restarted.

The "Storage Settings" display, accessed from the **Server Administration Settings** option in the **System** menu, shows the total storage space available for the virtual appliance, not the individual hard disks.

Note: To store large amounts of surveillance data, using a remote repository is recommended.

RAM settings: You can add RAM to the StruxureWare Central virtual appliance. You must gracefully shut down the virtual appliance to configure the settings.

CPU settings: You can add CPUs to the StruxureWare Central virtual appliance. You must gracefully shut down the virtual appliance to configure the settings.

Note: VMware supports fault tolerance on virtual machines with 1 CPU only. Please refer to your vendor's documentation for more information about fault tolerance.

Hardware resource configuration guidelines

Use the following guidelines to determine the hardware resources necessary for a StruxureWare Central virtual appliance to monitor a given number of device nodes.

Nodes	Hardware Resources
Up to 325 device nodes	1 GB RAM 1 CPU
Up to 1025 device nodes	2 GB RAM 1 CPU
Up to 2025 device nodes	2 GB RAM 2 CPU
Up to 4025 device nodes	4 GB RAM 4 CPU

Note: VMware supports fault tolerance on virtual machines with 1 CPU only. Please refer to your vendor's documentation for more information about fault tolerance.

The disk space required to monitor a given number of nodes varies according to the device types monitored and the amount of data you want to store. The minimum hard disk size is 18 GB.

To determine whether to add another hard disk, you can view available disk space in the "Storage Settings" display, accessed from the **Server Administration Settings** option in the **System** menu. View this display periodically to help determine how quickly the virtual appliance consumes disk space.

Note: To store large amounts of surveillance data, using a remote repository is recommended.

Fault tolerant configuration guidelines

Use the following guidelines to determine the hardware resources necessary for a StruxureWare Central virtual appliance fault tolerant configuration.

VMware supports fault tolerance on virtual machines with 1 CPU only. Please refer to your vendor's documentation for more information about fault tolerance.

Node Count	Hardware Resources
Up to 325 device nodes supported	1 GB RAM

	1 CPU
Up to 1025 device nodes supported	2 GB RAM 1 CPU

Note: The actual number of device nodes supported varies according to the device types discovered.

Minimum and maximum StruxureWare Central virtual appliance configurations

The demo configuration (minimum) and the maximum supported configurations for a StruxureWare Central virtual appliance are as follows.

For information about supported configurations equivalent to StruxureWare Central Basic, Standard, and Enterprise servers, see StruxureWare Central virtual appliance equivalent configurations.

Demo Configuration (minimum)	Hardware Resources
Up to five device nodes and one surveillance node	18 GB disk 1 GB RAM 1 CPU 1 network adapter Thin provisioning

Maximum supported configuration	Hardware Resources
Up to 4025 device nodes	1 TB disk 4 GB RAM 16 CPU 2 network adapters Thin or thick provisioning

Note: The actual number of device nodes supported varies according to the device types discovered.

Note: VMware supports fault tolerance on virtual machines with 1 CPU only. Please refer to your vendor's documentation for more information about fault tolerance.

StruxureWare Central server equivalent configurations

The StruxureWare Central virtual appliance equivalent configurations are based on StruxureWare Central Basic, Standard, and Enterprise server hardware configurations.

Hardware Server	Virtual Appliance Equivalent
-----------------	------------------------------

StruxureWare Central Basic	Up to 525 device nodes supported Up to 250 GB disk 1 GB RAM 2 CPU
StruxureWare Central Standard	Up to 2025 device nodes supported Up to 250 GB disk 2 GB RAM 2 CPU
StruxureWare Central Enterprise	Up to 4025 device nodes supported Up to 1 TB disk 4 GB RAM 4 - 16 CPU