# MS-PoE Injector User Manual



#### Copyright

© 2010 GE Security, Inc.

This document may not be copied in whole or in part or otherwise reproduced without prior written consent from GE Security, Inc., except where specifically permitted under US and international copyright law.

#### Disclaimer

The information in this document is subject to change without notice. GE Security, Inc. ("GE Security") assumes no responsibility for inaccuracies or omissions and specifically disclaims any liabilities, losses, or risks, personal or otherwise, incurred as a consequence, directly or indirectly, of the use or application of any of the contents of this document. For the latest documentation, contact your local supplier or visit us online at www.gesecurity.com.

This publication may contain examples of screen captures and reports used in daily operations. Examples may include fictitious names of individuals and companies. Any similarity to names and addresses of actual businesses or persons is entirely coincidental.

# Trademarks and patents

GE and the GE monogram are trademarks of General Electric Company.

Other trade names used in this document may be trademarks or registered trademarks of the manufacturers or vendors of the respective products.

#### Intended use

Use this product only for the purpose it was designed for; refer to the data sheet and user documentation for details. For the latest product information, contact your local supplier or visit us online at www.gesecurity.com.

#### FCC compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

i

# Regulatory information



#### Manufacturer

GE Security, Inc.

HQ and regulatory responsibility:

GE Security, Inc., 8985 Town Center Parkway,

Bradenton, FL 34202, USA

EU authorized manufacturing representative:

GE Security B.V., Kelvinstraat 7, 6003 DH Weert, The Netherlands

# European Union directives



2002/96/EC (WEEE directive): Products marked with this symbol cannot be disposed of as unsorted municipal waste in the European Union. For proper recycling, return this product to your local supplier upon the purchase of equivalent new equipment, or dispose of it at designated collection points. For more information see: www.recyclethis.info.

#### Contact information

For contact information see our Web site: www.gesecurity.com.

For contact information see our Web site: www.gesecurity.eu.

## Content

Chapter 1 Overview 1 Introduction 2

Chapter 2 Hardware Installation 7

# Chapter 1 Overview



The GE Security MS-PoE is an **IEEE 802.3af Power over Ethernet** Injector that provides 48VDC power over Ethernet cables (PoE).

#### **Package Contents**

Your MS-PoE injector carton should contain the following items:

- The Power over Ethernet Injector x 1
- User's Manual x 1

If any item is missing or damaged, please consult the dealer from whom you purchased you MS-PoE injector module.

#### Introduction

The GE Security MS-PoE IEEE 802.3af Power over Ethernet Injector inserts DC Voltage into Cat.5 cable, allowing the cable between the Injector (MS-PoE) and Splitter (SP-PoE) to transfer data and power simultaneously. The maximum distance between the Injector (MS-PoE) and Splitter (SP-PoE) is 100 meters. With MS-PoE installed, it is combines the Ethernet digital data with power over the twisted pair cables as an IEEE 802.3af Power over Ethernet Injector. The IEEE 802.3af Power over Ethernet splitter can separate the digital data and power into two outputs.

With IEEE 802.3af Power over Ethernet devices installed, the system administrator only has to use a single RJ-45 Ethernet cable to carry both power and data to each devices.


#### **Product Features**

- Complies with IEEE 802.3af Power over Ethernet, IEEE 802.3/802.3u 10/100Base-TX
- Provide DC 48V power over RJ-45 Ethernet cable to device with Ethernet port
- LED indicators power input indication
- Distance up to 100 meters
- Auto-detect of PoE IEEE 802.3af equipment, protects devices from being damaged by an incorrect installation
- Work with EIA568, category 5,4-pair cables for 10Base-T or 100Base-TX
- EMI standards comply with FCC, CE class B
- Saves time and reduces installation costs.
- Easy plug-and-play installation.

#### **Product Overview**

Figure 1 shows the right and left side views of the MS-PoE injector.

Figure 1: MS-PoE right and left side panels



#### **LED Indicators**

LED	Color	Function
Power	Yellow	Lights to indicate that the MS-PoE has power.
PoE ready / in-use	Green	Lights to indicate the port is providing 48VDC in-line power.

# **Product Specifications**

Model	MS-PoE				
Interface					
Ethernet Copper Port	1 x 10/100Base-TX for data in				
	RJ-45 connector				
Ethernet + DC Copper Port	1 x 10/100Base-TX with IEEE 802.3af PoE PSE for data + DC out				
	RJ-45 connector				
Power over Ethernet					
PoE Standard	IEEE 802.3af Power over Ethernet / PSE				
PoE Power Supply Type	Mid-Span / Type B				
Power PIN Assignment	4/5(+), 7/8(-)				
PoE Power Output	PoE 48V DC, Max. 15.4 watts, 350mA				
Number of device can be powered	1				
Hardware Specification	_				
Ethernet Data rate	10/100Mbps( vary on Ethernet device attached)				
Throughput(Packet per second)	148810@64Bytes				
Input Power	48V DC, 0.38A max.				
	1 x Power				
LED indicator	1 x PoE ready / in-use				
Installation	Standalone or wall mount				
Material	Plastic				
Standard Conformance	_				
	IEEE 802.3 Ethernet				
Standard Compliance	IEEE 802.3u Fast Ethernet				
	IEEE 802.3af Power over Ethernet				
Ethernet cable	TIA/EIA-568, Category 5/5e cable				

#### **Physical Specifications:**

Dimensions (W  $\times$  D  $\times$  H):

2.87" x 2.17" x 0.94" / 73 x 55 x 24mm

Weight:

0.22 lbs / 50g

#### **Environmental Specification**

Operating:

**Temperature:**  $0^{\circ}\text{C} \sim 50^{\circ}\text{C}$ 

**Relative Humidity:** 5% ~ 90% (non-condensing)

Storage:

**Temperature:** -20°C ~ 70°C

**Relative Humidity:** 5% ~ 90% (non-condensing)

### **Electrical Specification**

Input Voltage:

DC 48V, 0.38A

**NOTE:** This product is intended to be supplied by a UL Listed Direct Plug-In Power Unit marked "Class 2" or "LPS" and output rated 48 VDC, 3 Amp minimum.

#### Chapter 1: Overview

# Chapter 2 Hardware Installation

This product provides two different running speeds - 10Mbps, 100Mbps in the same device and automatically distinguishes the speed of the incoming connection.

This section describes the hardware installation of MS-PoE. Before connecting any network device to the MS-PoE, read this section carefully.

#### **Before Installation**

Before your installation, it is recommended that you check your network environment. If there are any IEEE 802.3af devices that you need to power. The MS-PoE can provide you a way to supply power for this Ethernet device conveniently and easily. The MS-PoE works with an AC-DC adapter (not supplied) with DC 48V input and injects this DC power into the pin of the twisted pair cable (pair 4, 5 and pair 7, 8 for Fast Ethernet).


If it is very difficult to find a power socket for an AC-DC Adapter of your non IEEE 802.3af networked device, the MS-PoE and SP-POE can provide you a way to supply DC power for this Ethernet device conveniently and easily.

**Note:** The MS-PoE and SP-POE can be installed in pair. However, the use of third-party device is allowed if the device complied with IEEE 802.3af standard.

#### Installing the MS-PoE

- 1. Connect a standard network cable from Switch/workstation to "Ethernet" port of MS-PoE.
- 2. Connect the long cable that will be used to connect to the remote device to the port "Ethernet + DC".
- 3. Connect an AC adapter to "DC 48V" of MS-PoE. The power LED will be steady on.
- **NOTE:** This product is intended to be supplied by a UL Listed Direct Plug-In Power Unit marked "Class 2" or "LPS" and output rated 48 VDC, 3 Amp minimum.
- 4. Connect with IEEE 802.3af devices, due to the capability of IEEE 802.3af standard, the MS-PoE can directly connect with any IEEE 802.3af end-nodes like wireless access point, VoIP phones and Internet camera where support IEEE 802.3af In-line Power over Ethernet port.

Figure 2: Connection to the IEEE 802.3af device




Once MS-PoE detects the existence of an IEEE 802.3af device, the LED indicator will stay steady, ON to show it is providing power.

**Note:** If the connected device is not fully complying with IEEE 802.3af standard or in-line power device, the LED indicator of MS-PoE will not be steady on.

# Installing an MS-PoE and a SP-POE, Injector and Splitter

- Connect a standard network cable from "Ethernet+DC" of MS-PoE to "Ethernet+DC" of SP-POE. The POE LED of MS-PoE / SP-POE will light on continuance.
- 2. Connect the UTP cable in the package from "Ethernet" of SP-POE to the RJ-45 port of remote device.
- 3. Connect proper DC plug from "DC OUT" of SP-POE to remote device.
- 4. Power on the remote device and the LED indicator on SP-POE will remains on.

Figure 3: Connection architecture over MS-PoE / SP-POE



#### Chapter 2: Hardware Installation

**Note:** According to IEEE 802.3af standard, the MS-PoE will not inject power to the cable if not connecting to IEEE 802.3af devices.

Please ensure the output voltage is correct before applying power to remote device.