

VIKING

TECHNICAL Practice

TELECOM SOLUTIONS FOR THE 21ST CENTURY

VE-MOUNT

Emergency Pool
Phone Mounting Kit

May 17, 2005

Turn Your E-30-EWP Into an Emergency Pool Phone



Many states are requiring an emergency phone to be installed near any outdoor swimming pool. The Viking **E-30-EWP** hands free phone is the perfect solution providing the auto-dialing and two-way voice communication required under these new regulations.

Mounting in a Viking **VE-5x5** chassis gives the **E-30-EWP** the rugged protection for the outdoors. The **VE-MOUNT** kit makes it easy to mount the **VE-5x5** chassis to any chain link fence. The kit has the brackets and hardware that allow easy bolt-on installation, and a peel and stick label for identifying the phone. Also a telephone jack is included to allow access to the Viking Auto-Programming System.

Let your customer know that you have the solution to these new requirements with the Viking **E-30-EWP**, **VE-5x5** and the **VE-MOUNT** kit.

Features

- Heavy gauge steel brackets
- All required mounting hardware included
- Durable outdoor rated label
- Telephone jack for Auto-Programming

Applications

- Converts an **E-30-EWP** to an Emergency Pool Phone
- Provides easy mounting to chain link fences
- For use at:
 - Private swimming pools
 - Club and organization pools
 - Public pools

Made in the U.S.A.

Phone...715.386.8861

info@vikingelectronics.com

<http://www.vikingelectronics.com>

Specifications

Label Material: Lexan
Bolt Size: 5/16" x 1-1/2"
Shipping Weight: 1 lb

IF YOU HAVE A PROBLEM WITH A VIKING PRODUCT, PLEASE CONTACT: VIKING TECHNICAL SUPPORT AT (715) 386-8666

Our Technical Support Department is available for assistance Monday 8am-4pm and Tuesday-Friday 8am - 5pm central time. So that we can give you better service, before you call please:

1. Know the model number, the serial number and what software version you have (see serial label).
2. Have your Technical Practice in front of you.
3. It is best if you are on site.

RETURNING PRODUCT FOR REPAIR

The following procedure is for equipment that needs repair:

1. Customer must contact Viking's Technical Support Department at 715-386-8666 to obtain a Return Authorization (RA) number. The customer MUST have a complete description of the problem, with all pertinent information regarding the defect, such as options set, conditions, symptoms, methods to duplicate problem, frequency of failure, etc.
2. Packing: Return equipment in original box or in proper packing so that damage will not occur while in transit. Static sensitive equipment such as a circuit board should be in an anti-static bag, sandwiched between foam and individually boxed. All equipment should be wrapped to avoid packing material lodging in or sticking to the equipment. Include ALL parts of the equipment. C.O.D. or freight collect shipments cannot be accepted. Ship cartons prepaid to:
Viking Electronics, 1531 Industrial Street, Hudson, WI 54016
3. Return shipping address: Be sure to include your return shipping address inside the box. We cannot ship to a PO Box.
4. RA number on carton: In large printing, write the R.A. number on the outside of each carton being returned.

RETURNING PRODUCT FOR EXCHANGE

The following procedure is for equipment that has failed out-of-box (within 10 days of purchase):

1. Customer must contact Viking's Technical Support at 715-386-8666 to determine possible causes for the problem. The customer MUST be able to step through recommended tests for diagnosis.
2. If the Technical Support Product Specialist determines that the equipment is defective based on the customer's input and troubleshooting, a Return Authorization (R.A.) number will be issued. This number is valid for fourteen (14) calendar days from the date of issue.
3. After obtaining the R.A. number, return the approved equipment to your distributor, referencing the R.A. number. Your distributor will then replace the product over the counter at no charge. The distributor will then return the product to Viking using the same R.A. number.
4. **The distributor will NOT exchange this product without first obtaining the R.A. number from you. If you haven't followed the steps listed in 1, 2 and 3, be aware that you will have to pay a restocking charge.**

WARRANTY

Viking warrants its products to be free from defects in the workmanship or materials, under normal use and service, for a period of one year from the date of purchase from any authorized Viking distributor or 18 months from the date manufactured, whichever ever is greater. If at any time during the warranty period, the product is deemed defective or malfunctions, return the product to Viking Electronics, Inc., 1531 Industrial Street, Hudson, WI, 54016. Customer must contact Viking's Technical Support Department at 715-386-8666 to obtain a Return Authorization (R.A.) number.

This warranty does not cover any damage to the product due to lightning, over voltage, under voltage, accident, misuse, abuse, negligence or any damage caused by use of the product by the purchaser or others.

Viking's sole responsibility shall be to repair or replace (at Viking's option) the material within the terms stated above. VIKING SHALL NOT BE LIABLE FOR ANY LOSS OR DAMAGE OF ANY KIND INCLUDING INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING DIRECTLY OR INDIRECTLY FROM ANY BREACH OF ANY WARRANTY EXPRESSED OR IMPLIED, OR FOR ANY OTHER FAILURE OF THIS PRODUCT. Some states do not allow the exclusion or limitation of incidental or consequential damages, so this limitation may not apply to you.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY EXCLUDED BEYOND THE ONE YEAR DURATION OF THIS WARRANTY. Some states do not allow limitation on how long an implied warranty lasts, so the above limitation may not apply to you.

Installation

Mount the **VE-5x5** enclosure to the chain link fence as shown in Figure 1. Connect the incoming phone line to the **E-30-EWP** phone line input (refer to the **E-30-EWP** Technical Practice). Peel the backing off of the phone label and place it on the faceplate (see Figure 2). If using Auto-Programming, twist the phone line wires, the **E-30-EWP** wires and the telephone jack wires together. **DO NOT USE THE GEL-FILLED CONNECTORS** supplied with the **E-30-EWP** (see figure 3). Once programming is completed, remove the telephone jack and use the Gel-filled connectors to finish the installation.





Figure 1



Programming

To use the Auto-Programming System, lift the handset on the Programming Phone and call (715) 377-0185. Follow the voice prompts and enter the number you wish the **E-30-EWP** to dial. Once the number is entered, hangup the phone and wait for the programming process to complete (about 30 seconds).




Figure 3

Product Support Line...715.386.8666

Fax Back Line...715.386.4345

Due to the dynamic nature of the product design, the information contained in this document is subject to change without notice. Viking Electronics, and its affiliates and/or subsidiaries assume no responsibility for errors and omissions contained in this information. Revisions of this document or new editions of it may be issued to incorporate such changes.