## **Installation Instructions**

Model Number 1078-WA


#### Model 1078-WA Locking Recess Wall/Ceiling Mount Assembly Components:

- Ceiling enclosure Model 1078-WA assembly 1 each
- Wall bridge 2 each
- #8-32 X 3/8 " screw 4 each
- #8-32 nut 4 each
- 3/4" Trade size conduit connector 1 each
- Fire block foam 1 each
- Keys for access door lock 2 each
- Installation instructions 1 each
- Evebolt 4 each
- Support wire 4 each


If any of these items are missing, contact your Oberon representative.

Find a flat work surface to assemble the enclosure, access point and antenna(s) (if needed) prior to mounting in wall or ceiling.

**Step 1** - Cut a 13" horizontal x 13.4" vertical opening in the "hard lid" ceiling or wall (special cutting tools may be required ref. Figure 1).



bridges extended towards the bottom. The wall bridges will go in first. Once the bottom of the enclosure is in the hole push the enclosure so it is flush with the wall or ceiling.



This product is Listed by Underwriters Laboratories Inc. Representative


samples of this product have been


evaluated by UL and meet applicable

safety standards.


Step 2 – Place the enclosure assembly on the work surface. Remove one of the 1" trade size hole cover on the side of the enclosure and install the 1" trade size conduit connector (the side on which the trade size cable clamp is to be installed will be determined by the location the enclosure is to be installed and direction from which conduit will be brought into the enclosure – ref. Figure 2).

Step 3 – Place the (2) two wall bridges in the mounting position by loosing the (4) four wing nuts inside of the enclosure. The position of the wall bridges will look like the image in Figure 3. Place the enclosure in to the hole that was cut in Figure 1. Angle the enclosure at 10° with the wall






Step 4 – Once the enclosure is flush with the wall or ceiling, slide the wall bridges in the L-slot, and draw the bridges against the wall. Tighten the wing nuts one side at a time (Figure 4). At this point, the enclosure is ready to be "mudded" into the wall. Additional material my be needed.



A\*\*IMPORTANT\*\* - This is an important safety feature that could prevent human injury or damage to the access point should the unit become dislodged from the wall or ceiling.

Rev. B1 05/23/13



Page 3


Step 5 – Unlock and open the door. Use the manufacturers T-Bar mount clip to attach the access point to the T-Bar Section on the mounting plate. An additional mounting plate provided by the manufacturer of the access point may be needed to attach the access point (Figure 5). Data cable(s) may need to be plugged in to the access point prior to attaching to the mount. Cisco access points use Cisco AIR-AP-BRACKET-2 for 2600/3600 series access points and AIR-AP-BRACKET-1 for 1140/3500 series.


Step 6 - Once the assembly has been installed in the wall or ceiling and secured using wall bridges, open the door and run the Ethernet cable into the enclosure through the conduit connector located on the side of the access point enclosure and attach to the access point prior to installing. Insert foam into the conduit connector and pull the data cable through far enough to allow attachment to the access point (8" - 10"). Tighten cable clamp around foam fire block so that there are no air gaps. Be careful not to over tighten and crush the Ethernet cable(s). Reference Figure 6.

Step 7 - Once the access point is secured and power and Ethernet are connected, lock the door. The installation is now complete.

### If Placing Enclosure In A Ceiling

Step 8 – If placing enclosure into a ceiling remove the (4) screws in the corner of the backbox and thread the (4) eyebolts (included) into the backbox and lock into place using the (4) evebolt nuts (included). Attach the hanger wires to the evebolts and then to a permanent structure within the ceiling.







# \*\*\*\* WARNING \*\*\*\*

## Please thoroughly read the product warning below before installation to provide for a safe work environment.

- resistance.
- from accidentally swinging open.
- exceed this temperature, depending on power dissipation within enclosure.
- maintained for the safe operation of the equipment.
- 6. This product is intended to be installed by trained personnel.
- 7. Only Listed ITE products and Listed AC Receptacles shall be installed within the enclosure.
- replacement.
- 9. Maximum weight to be installed in the unit is 25 lbs.
- complies with UL 2043 or UL 1479.
- 11. All unused mounting holes should be sealed with tape or other material that complies with UL 1479.
- knockout in the backbox.



Installation Instructions

1. Ceiling mounted products should be installed in accordance with National Electric Code paragraphs 300.10 (Electrical Continuity of Metal Raceways and Enclosures) and 300.11 (Securing and Supporting). Independent support wires or other means must be used for the installation of this product in the ceiling. Acoustical, suspended, false, drop and concealed spline ceiling grid work is not designed to support the weight of this product. Oberon's ceiling mounted products have four support wire tabs on the back box. These tabs shall be used for supporting the product with independent support wires, wire rope, threaded rod, or other secure support means of adequate gauge and fire

2. When closing the enclosure access door, be sure that the cam lock is completely engaged to prevent the access door

3. When opening the enclosure door, be sure to support the door to prevent the door from accidentally falling open.

4. This enclosure has a maximum operating ambient of 55° C (131° F), the temperature within the enclosure may not

5. A minimum air clearance of 1" between the housing of the access point and the enclosure side walls must be

8. This product is to be repaired by personnel trained by the manufacturer or returned to the manufacturer for repair or

10. All knockouts, openings, and holes shall be sealed with a plug constructed of metal, or a non-metal material that

12. If AC power is used inside the enclosure, connect the ground wire to the green ground screw located near the