


GENERAL SAFETY GUIDELINES

- * ALWAYS PERSONALLY ENSURE THAT ELECTRICAL POWER HAS BEEN DISCONNECTED BEFORE WORKING ON OR INSTALLING A COMPONENT.
- * DO NOT PERFORM ANY ACTION THAT MAY CREATE A POTENTIAL HAZARD TO OTHERS OR MAKE EQUIPMENT UNSAFE.
- * CHECK THE WORK AREA FOR ANY POTENTIAL HAZARDS AND RESOLVE THEM BEFORE BEGINNING ANY WORK.
- * DO NOT ATTEMPT TO LIFT OBJECTS THAT ARE TOO HEAVY TO BE LIFTED SAFELY BY YOURSELF.
- * KEEP WALK AREAS CLEAR OF TOOLS AND ASSEMBLY COMPONENTS.
- * NEVER WORK ALONE WHEN POTENTIALLY HAZARDOUS CONDITIONS EXIST.
- * DO NOT WEAR LOOSE CLOTHING, JEWELRY, OR ANY OTHER ITEMS THAT MIGHT GET CAUGHT IN THE ASSEMBLY. SECURE ANY DANGLING CLOTHING ACCESSORIES, SUCH AS TIES, SCARVES, OR SLEEVES.
- * NEVER INSTALL DAMAGED EQUIPMENT.



INSTALLATION INSTR FAN KIT CABINET

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION, DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.



1. READ AND FOLLOW ALL SAFETY GUIDELINES ON PAGE 1 BEFORE BEGINNING INSTALLATION.
2. ENSURE THAT ELECTRICAL POWER IS REMOVED FROM FAN ASSEMBLIES BEFORE BEGINNING INSTALLATION.
3. REMOVE TOP PANEL FROM CABINET OR FRAME.
4. LAY FAN ASSEMBLIES AND TOP PANEL ON FLAT SURFACE IN INVERTED POSITION AS COMPARED TO PICTORIAL VIEW BELOW.
5. FOR ALL CABINETS EXCEPT 22" DEEP SLIMFRAME, FAN ASSEMBLY INPUT POWER PLUGS SHOULD FACE EACH OTHER AS SHOWN. FOR 22" DP SLIMFRAME, INPUT PLUGS SHOULD FACE AWAY FROM EACH OTHER.
6. ALIGN HOLES IN FLANGES OF FAN ASSEMBLIES WITH HOLES IN TOP PANEL.
7. INSTALL AND TIGHTEN 6-32 SCREWS AND NUTS SUPPLIED.

CPI CHATSWORTH PRODUCTS, INC.


INSTALLATION INSTR FAN KIT CABINET

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION, DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.

8. PEEL THE BACKS FROM THREE CABLE-TIE MOUNTS (SUPPLIED) AND PLACE THEM AS SHOWN BELOW. FOR 22" DEEP SLIMFRAME, LOCATE CABLE TIE MOUNTS SO THAT POWER CORD IS ROUTED ACROSS CENTER OF FAN HOUSING (SHOULD NOT INTERFERE WITH FAN GRILLE).
9. VISUALLY INSPECT POWERCORD CABLE FOR ANY EXTERNAL DEFECTS (LOOSE PARTS, DEFORMED OR MISSING PINS, DAMAGE TO OUTER JACKET, ETC.) AND FOR ANY SIGNS OF POSSIBLE INTERNAL DAMAGE (CRUSHED OUTER JACKET MAY HAVE CAUSED INTERNAL DAMAGE).
10. THREAD CABLE TIES THROUGH THE MOUNTS AND LAY POWERCORD CABLE IN PLACE AS SHOWN BELOW.

11. PLUG THE POWERCORD CABLE CONNECTORS INTO THE INPUT POWER PLUGS ON THE FAN ASSEMBLIES. THE CONNECTORS MAY BE PLUGGED INTO EITHER OF THE FAN ASSEMBLIES.

12. FASTEN CABLE TIES FIRMLY (USE EXTRA CABLE-TIE MOUNT IF NEEDED). ALLOW ENOUGH SLACK SO THE CONNECTIONS ARE NOT STRAINED.
13. RE-INSTALL TOP PANEL ASSEMBLY INTO CABINET OR FRAME.



CPI CHATSWORTH PRODUCTS, INC.

INSTALLATION INSTR FAN KIT CABINET

THIS DRAWING CONTAINS INFORMATION PROPRIETARY TO CHATSWORTH PRODUCTS, INC. ANY REPRODUCTION, DISCLOSURE OR USE OF THIS DRAWING IS EXPRESSLY FORBIDDEN EXCEPT AS AGREED TO IN WRITING BY CHATSWORTH PRODUCTS, INC.