

ETP-EL Installation Instructions



THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED

CE PRODUIT DOIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS

I. Introduction

Model **ETP-EL** is a 120VAC outdoor-rated Blue Light, which is lit at all times to draw attention to the location. The Blue Light flashing can be activated by Talk-A-Phone emergency phones or by third party devices that provide a dry contact closure or relay output.

II. Power requirements

ETP-EL: 96-132VAC, 7.8 Watts (35A peak inrush)

III. Mounting

If installing the Blue Light in a Talk-A-Phone phone mount, such as an **ETP-MT** mounting tower, follow the instructions included with that mount. Alternatively, remotely mount the Blue Light to a 4" square conduit box using an **ETP-MBKT** mounting bracket. Screws are included with the mount or bracket.

IV. Wiring

The **ETP-EL** (polycarbonate base) Blue Light can be connected to the 120VAC output voltage of the power source (shown in **Figure 1**). The **ETP-EL** (aluminum base) Blue Light can be connected to the 120VAC output voltage of the power source, while grounding the green wire (shown in **Figure 2**).

V. Connecting to Emergency Phone

When using the Blue Light with **ETP-400** Series Emergency Phones, connect the orange and black auxiliary control cable pair of the Blue Light to the orange and black wires of the Emergency Phone. Refer to the Emergency Phone Manual for information regarding the programming of your phone.

When using the **ETP-EL** Series Blue Light with **VOIP-500** Series Emergency Phones, connect the orange and black auxiliary control cable pair of the Blue Light to positions 3 and 4 (Aux. Output 2) of the 6-pin connector plug of the **VOIP-500** Series Phone.

ETP-EL Installation Instructions




Figure 1: Electrical connections to the ETP-EL (polycarbonate base) Blue Light




Figure 2: Electrical connections to the ETP-EL (aluminum base) Blue Light